

Suspension System

GENERAL

SPECIFICATIONS	SS-2
LUBRICANTS	SS-5
SPECIAL TOOLS	SS-5
TROUBLESHOOTING	SS-8

FRONT SUSPENSION SYSTEM

FRONT STRUT ASSEMBLY

COMPONENTS	SS-10
REMOVAL	SS-11
INSTALLATION	SS-11
DISASSEMBLY	SS-12
INSPECTION	SS-12
REASSEMBLY	SS-12

FRONT LOWER ARM

COMPONENTS	SS-14
REMOVAL	SS-15
INSTALLATION	SS-15
REPLACEMENT	SS-15
INSPECTION	SS-17

FRONT STABILIZER BAR

COMPONENTS	SS-18
REMOVAL	SS-18
INSPECTION	SS-19
INSTALLATION	SS-19

REAR SUSPENSION SYSTEM

REAR SUSPENSION ARM

COMPONENTS	SS-20
REMOVAL	SS-21
INSPECTION	SS-21
INSTALLATION	SS-21

REAR STRUT ASSEMBLY

COMPONENTS	SS-22
REMOVAL	SS-23
DISASSEMBLY	SS-23
INSPECTION	SS-24
REASSEMBLY	SS-24

TRAILING ARM

REMOVAL	SS-26
REPLACEMENT	SS-26

REAR STABILIZER BAR

REMOVAL	SS-28
INSPECTION	SS-28
INSTALLATION	SS-28

TIRES / WHEELS

DESCRIPTION	SS-29
TIRE	
ADJUSTMENT	SS-30
WHEEL	
ADJUSTMENT	SS-32

GENERAL

SPECIFICATIONS

E3F4F022

Front suspension system			Macpherson strut type		
Shock absorber					
Type			Gas type		
Stroke mm (in)			160.4 (6.32)		
Damping force at 0.3 m/s			Normal		
Expansion N(kg)			940 ± 140 (94 ± 14)		
Compression N(kg)			260 ± 60 (26 ± 6)		
ID color			Red		
Sports					
			2080 ± 290 (208 ± 29)		
			430 ± 90 (43 ± 9)		
			Blue		
Coil spring free height and identification color					
Model			Classification	Free height mm (in.)	ID color
2.0L GL	M/T (-A/CON)		Sports	323.3 (12.73)	Blue-Blue
2.0L GLS	M/T (-A/CON)		Normal	340.9 (13.42)	Yellow-Yellow
2.0L GLS	6M/T (-A/CON)				
2.0L GL	A/T (-A/CON)		Sports	329.2 (12.96)	Green-Green
2.0L GL	M/T (+A/CON)		Normal	347.6 (13.69)	Pink-Pink
2.0L GLS	M/T (+A/CON)				
2.0L GLS	6M/T (+A/CON)				
2.0L GLS	A/T (-A/CON)				
2.0L GL	A/T (+A/CON)		Sports	335.1 (13.19)	Violet-Violet
2.0L GLS	A/T (+A/CON)		Normal	354.3 (13.95)	Red-Red
2.7L GL	6M/T (+A/CON)				
2.7L GL	A/T (+A/CON)				
2.7L GLS	6M/T (+A/CON)				
2.7L GLS	A/T (+A/CON)				

* GL, GLS : Trim level

* M/T : 5 speed manual transaxle

* A/T : Automatic transaxle

* ID : Identification

* A/CON : With air conditioning

* N-A/CON : Without air conditioning

* 6M/T : 6 Speed Manual transaxle

Rear suspension system

Dual link

Shock absorber

Type

Gas type

Stroke mm (in)

183.8 (7.24)

Damping force at 0.3 m/s

Normal**Sports**

Expansion N(kg)

590 ± 100 (59 ± 10)

1020 ± 150 (102 ± 15)

Compression N(kg)

190 ± 50 (19 ± 5)

380 ± 80 (38 ± 8)

ID color

Red

Blue

Coil spring free height and identification color

Model	Classification	Free height mm (in.)	I.D color
2.0L GL A/T (-S/R)	Sports	311.0 (12.24)	White-White
2.7L GLS 6M/T (-S/R)	Normal	320.5 (12.62)	Red-Red
2.0L GL M/T (ALL)	Sports	315.6 (12.43)	Blue-Blue
2.0L GL A/T (+S/R)			
2.0L GL M/T (+S/R)			
2.0L GLS (ALL)			
2.7L GL 6M/T (+S/R)	Normal	325.6 (12.82)	Yellow-Yellow
2.7L GL A/T (ALL)			
2.7L GLS (ALL)			

* GL, GLS : Trim level

* 6M/T : 6 Speed Manual transaxle

* M/T : 5 speed manual transaxle

* +S/R : With Sun roof

* A/T : Automatic transaxle

* -S/R : Without Sun roof

* ID : Identification

SERVICE STANDARD

Standard value		
Toe-in mm (in.)	Front	-2 ~ +2 (-0.08 ~ ±0.08) (Max. difference between LH and RH : 1.5 mm)
	Rear	4^{+3}_{-1} (0.16 $^{+0.12}_{-0.04}$) (Max. difference between LH and RH : 2 mm)
Camber	Front	-0°13' ± 30' (Max. difference between LH and RH : 0°30')
	Rear	-1°11' ± 30' (Max. difference between LH and RH : 30')
Caster	Front	3°23' ± 30' (Max. difference between LH and RH : 0°30')
King pin angle	Front	12°42' ± 30'
King pin offset	mm (in.) Front	-3.44 (-0.135)
Side slip	mm (in.) Front	±3
	Rear	2-9 (when forwarding 1m)
Tire size	205/55 R16, 215/45 R17, T125/70 R16 (Temporary tire)	
Wheel size	6.5J x 16, 7.0J x 17 (Aluminum wheel)	
Tire inflation pressure kgf/cm ² (PSI)	2.1 $^{+0.07}_{-0}$ (30 $^{+1}_{-0}$), 215/45 R17 tire only : 2.2 $^{+0.07}_{-0}$ (32 $^{+1}_{-0}$), Temporary tire : 4.2(60)	

EHOF010C

**CAUTION**

When rotating the "215/45 R17" Tires, ensure to follow the "ROTATION" direction marked on the sidewall of tires (see page SS-30).

TIGHTENING TORQUE

Items	Nm	kgf·cm	lbf·ft
Wheel nut	90~110	900~1100	67~82
Driveshaft nut			
2.0L	200~260	2000~2600	148~192
2.7L	200~280	2000~2800	148~207
Front strut upper installation nut	45~60	450~600	33~44
Front strut assembly to knuckle	140~160	1400~1600	104~118
Front strut mounting self-locking nut	50~70	500~700	37~51
Lower arm ball joint to knuckle	60~72	600~720	43~52
Lower arm bushing (A) mounting bolt	130~150	1300~1500	96~111
Lower arm bushing (G) mounting bolt	130~150	1300~1500	96~111
Stabilizer bar bracket mounting bolt	30~45	300~450	22~33
Tie rod end ball joint to knuckle	24~34	240~340	18~25
Tie rod end lock nut	50~55	500~550	37~41
Stabilizer link nut	35~45	350~450	26~33
Rear strut upper mounting nut	30~40	300~400	22~30
Rear strut lower mounting nut	110~130	1100~1300	81~96
Rear strut mounting self locking nut	40~60	400~600	30~44
Rear stabilizer link to stabilizer bar	35~45	350~450	26~33
Rear stabilizer bar bracket bolt	17~26	170~260	13~19

Items	Nm	kgf·cm	lbf·ft
Rear suspension arm tie rod nut	50~60	500~600	37~43
Rear suspension arm (A,B) mounting bolt	160~180	1600~1800	118~133
Rear cross member mounting bolt	100~120	1000~1200	74~88
Trailing arm to bracket nut	40~50	400~500	30~37
Trailing arm bracket to body frame	40~50	400~500	30~37
Trailing arm mounting	100~120	1000~1200	74~88

**CAUTION**

Replace the self-locking nuts with new ones after removal.




LUBRICANTS







E44ED2EE



Item	Recommended lubricant	Quantity
In ball joint of lower arm	Variant R-2 grease or poly lub gly 801K	As required

SPECIAL TOOLS

EA3CE969




Tool (Number and Name)	Use	Illustration
09216-21100 Mount bushing remover and installer	 B1621100	Removal & installation of lower arm bushing (G) (Use with 09216-21200, 09545-02000)
09216-21200 Mount bushing remover and installer base	 B1621200	Removal & installation of the lower arm bushing (G) (Use with 09216-21100, 09545-02000)
09532-11600 Preload socket	 E3211600	Measurement of the lower arm ball joint & stabilizer link starting torque




Tool (Number and Name)	Use	Illustration
09545-02000 Lower arm bushing remover and installer	 E4502000	Removal & installation of the lower arm bushing (G) (Use with 09216-21100, 09216-21200)
09545-11000 Ball joint remover and installer	 E4511000	Installation of the lower arm ball joint
09545-21100 Ball joint dust cover installer	 E4521100	Installation of the lower arm ball joint dust cover
09551-25000 Trailing arm bushing remover and installer	 E5125000	Removal & installation of the trailing arm bushing
09552-25000 Rear suspension arm bushing remover and installer	 EHDA140H	Removal & installation of the rear suspension arm bushing (Use with 09545-28100)
09568-34000 Ball joint puller	 E6834000	Separation of the lower arm ball joint

Tool (Number and Name)	Use	Illustration
09546-26000 Strut spring compressor or J38402 Strut spring compressor	 E4626000 EHDA140K	Compression of front coil spring Compression of the front and rear coil spring (Use with A-42 or A-20)
09624-34000 Trailing arm bushing remover and installer	 F2434000	Removal and installation of the lower arm bush (G)

TROUBLESHOOTING EE139B4C

Symptom	Possible cause	Remedy
Hard steering	Improper front wheel alignment Excessive turning resistance of lower arm ball joint Low tire pressure No power assist	Correct Replace Adjust Repair and replace
Poor return of steering wheel to center	Improper front wheel alignment	Correct
Poor or rough ride	Improper front wheel alignment Malfunctioning shock absorber Broken or worn stabilizer Broken or worn coil spring Worn lower arm bushing	Correct Repair or replace Replace Replace Replace the lower arm assembly
Abnormal tire wear	Improper front wheel alignment Improper tire pressure Malfunctioning shock absorber	Correct Adjust Replace
Wandering	Improper front wheel alignment Poor turning resistance of lower arm ball joint Loose or worn lower arm bushing	Correct Repair Retighten or replace
Vehicle pulls to one side	Improper front wheel alignment Excessive turning resistance of lower arm ball joint Broken or worn coil spring Bent lower arm	Correct Replace Replace Repair
Steering wheel shimmy	Improper front wheel alignment Poor turning resistance of lower arm ball joint Broken or worn stabilizer Worn lower arm bushing Malfunctioning shock absorber Broken or worn coil spring	Correct Replace Replace Replace Replace Replace
Bottoming	Broken or worn coil spring Malfunctioning shock absorber	Replace Replace


WHEEL AND TIRE DIAGNOSIS		
Rapid wear at the center	Rapid wear at both shoulders	Wear at one shoulder
		
KXDT001A	KXDT002A	KXDT003A
<ul style="list-style-type: none"> Center- tread down to fabric due to excessive over inflated tires Lack of rotation Excessive toe on drive wheels Heavy acceleration on drive 	<ul style="list-style-type: none"> Underinflated tires Worn suspension components Excessive cornering speeds Lack of rotation 	<ul style="list-style-type: none"> Toe adjustment out of specification Camber out of specification Damaged strut Damaged lower arm

WHEEL AND TIRE DIAGNOSIS		
Partial wear	Feather edges wheels	Wear pattern
		
KXDT004A	KXDT005A	KXDT006A
<ul style="list-style-type: none"> Caused by irregular burrs on brak drums. 	<ul style="list-style-type: none"> Toe adjustment out of specification Damaged or worn tie rods Damaged knuckle 	<ul style="list-style-type: none"> Excessive toe on non-drive wheels Lack of rotation

FRONT SUSPENSION SYSTEM

FRONT STRUT ASSEMBLY

COMPONENTS E6E9D3C7



REMOVAL E17CCED1


1. Remove the front wheel.
2. Detach the brake hose bracket from the strut assembly.



NOTE


Do not apply excessive force to the components.

3. Remove the stabilizer link.




EHOF110B

4. Remove the strut upper mounting bolts(3).



EHOF110C


5. Remove the strut assembly.



EHOF110D

INSTALLATION E593AD02

1. When installing the front strut, be sure to clear the connecting surface.
2. Install the strut assembly so the identification label on the strut insulator faces toward the inside of vehicle.



EFCSS03A

3. Tighten the components below to the specified torque as follows.

Items	Torque Nm (kgf·cm, lbf·ft)
Front strut upper mounting nut	45~60 (450~600, 33~44)
Front strut to knuckle	140~160 (1400~1600, 104~118)
Stabilizer link nut	35~45 (350~450, 26~33)


4. Install the brake hose and front wheel speed sensor wire on the front strut assembly.

DISASSEMBLY E4E7801C

- Using the special tools (09546-26000 or J38402), compress the coil spring until there is only a little tension on the strut.

**NOTE**

Do not use an impact gun.




EHOC100A

- Remove the nut at the top end of shock absorber.
- Remove the insulator, spring seat, coil spring, dust cover from the strut assembly.

INSPECTION EC2D49D3

- Check the strut insulator bearing for wear or damage.
- Check rubber parts for damage or deterioration.
- Check the coil spring for sagging and weakness.
- Check the shock absorber for abnormal resistance or unusual sound.



EHOF112A

DISPOSAL


- Fully extend the shock absorber rod.

- Drill a hole on the A section to remove gas from the cylinder.

**CAUTION**

The gas coming out is harmless, but be careful of chips that may fly when drilling.


Be sure to wear face shield and safety goggles.



EHOF112B

REASSEMBLY ED8819B1

- Install lower spring pad so that the protrusions fit in the holes of the spring lower seat.



EHOF113A

- Install the dust cover on the shock absorber.
- Using the special tools (09546-26000 or J38402), compress the coil spring. After the spring is fully compressed, install it on the shock absorber.

**NOTE**


Install the coil spring with the identification mark directed toward the knuckle.

4. After fully extending the piston rod, install the spring upper seat and insulator assembly.




NOTE

Align the D-shaped hole in the spring seat upper assembly with the protrusion on the piston rod.



EHOF113B

5. After seating the upper and lower ends of the coil spring in the upper and lower spring seat grooves correctly, tighten the new self-locking nut temporarily.



EHOF113D


6. Remove the special tool (09546-26000 or J38402).
7. Tighten the self-locking nut to the specified torque.

Tightening torque

50~70 Nm (500~700 kgf·cm, 37~51 lbf·ft)

FRONT LOWER ARM


COMPONENTS E1E137EC



TORQUE : Nm (kgf·cm, lbf·ft)


REMOVAL EAAE468E

1. Remove the front wheel.
2. Remove the driveshaft split pin, nut and washer.
3. Loosen the lower arm ball joint nut, but do not remove it.
4. Remove the strut lower mounting bolts(2).



EHOF120B

5. Push the axle hub toward the outside to disconnect the driveshaft from the axle hub.
6. Using the special tool (09568 - 34000), disconnect the lower arm ball joint from the lower arm.



EIOF150D

7. Temporarily install the strut lower mounting bolt.
8. Remove the lower arm bushing (A) and bushing (G) mounting bolts(2).
9. Remove the lower arm assembly.

INSTALLATION EC16F4AB

Installation is in the reverse order of removal.



NOTE


Tighten the components below to the specified torque as follows.

Items	Torque Nm (kgf-cm, lbf-ft)
Wheel nut	90~110 (900~1100, 67~82)
Driveshaft nut	2.0 L : 200~260 (2000~2600, 148~192) 2.7 L : 200~280 (2000~2600, 148~192)
Strut lower mounting	140~160 (1400~1600, 104~118)
Lower arm ball joint nut	60~72 (600~720, 43~52)
Lower arm bushing(A)	130~150 (1300~1500, 96~111)
Lower arm bushing(G)	130~150 (1300~1500, 96~111)
Stabilizer link nut	35~45 (350~450, 26~33)

REPLACEMENT EA31E3DF

BALL JOINT AND DUST COVER

1. Using a flat-tipped screwdriver, remove the dust cover from the lower arm ball joint.




EHDA253D

2. Remove the snap ring.
3. Using a plastic hammer, tap the ball joint out of the lower arm.


LOWER ARM BUSHING (G)

1. Install the special tools (09545-02000, 09216-21100 and 09216-21200) on the lower arm.
2. Press out the bushing.




EHOF124A

4. Using special tool (09545 - 11000), press-fit the ball joint into the lower arm assembly.




EHOF124B

5. Install the snap ring.
6. Using the special tool (09545 - 21100), install the dust cover.




EHOF124C



EHOF124D

3. Apply soap solution to the following parts.
 - Outer surface of the bushing
 - Inner surface of the lower arm bushing mounting part.
4. Install the new bushing on the lower arm by using special tools (09216-21100, 09624-34000).




EHOF124E

**NOTE**

Press-in the lower arm bushing (G) in the same direction as shown in illustration.

Pull out force for the bushing
80 N [800 kg(f), 11.9 lb(f)] or more



EHOE170A

- If there is a crack in the dust cover, replace the ball joint assembly.
- Shake the ball joint stud several times.
- Measure the ball joint rotating torque.

Standard value


2.0~3.5 Nm (20~35 kgf·cm, 1.48~2.58 lbf·ft)

- If the rotating torque is above the upper limit of the standard value, replace the ball joint assembly.
- Even if the rotating torque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.


INSPECTION

ECBE222C


1. Check the bushing for wear and deterioration.
2. Check the lower arm for bending or breakage.
3. Check the ball joint dust cover for cracks and damage.
4. Check all bolts for damage and deformation.
5. Check the lower arm ball joint for rotating torque.



EHOE122A




EHOE122B

FRONT STABILIZER BAR**COMPONENTS** E30A6749**TORQUE : Nm (kgf-cm, lbf-ft)**


REMOVAL EB0AED88

1. Remove the front wheel.
2. Remove the stabilizer link assembly.



EHOF110B

3. Remove the stabilizer bracket and bushing.




EHOF130C

4. Remove the stabilizer bar.

INSPECTION EAFB99FA

1. Check the stabilizer bar for deterioration and damage.
2. Check all bolts for damage and deformation.
3. Check the stabilizer link dust cover for cracks or damage.
4. Check the stabilizer link ball joint for rotating torque.



EHOF132A

- If there is a crack in the dust cover, replace it and add grease.
- Shake the stabilizer link ball joint stud several times.
- Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

Standard value

0.7~2 Nm (7~20 kgf·cm, 0.52~1.48 lbf·ft)

- If the rotating torque is higher than the upper limit of the standard value, replace the stabilizer link.
- If the rotating torque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

INSTALLATION

E035E417

1. Install the bushing on the stabilizer bar.


**NOTE**

- a. When installing the stabilizer bar, follow the identification color (ID color) as below.

Model	ID color	Outer diameter
2.0L Sports (HARD)	-	21.8mm (0.86 in.)
2.0L Normal (SOFT)	White	18.8mm (0.74 in.)
2.7L Sports (HARD)	Yellow	21.8mm (0.86 in.)
2.7 Normal (SOFT)	Red	18.8mm (0.74 in.)

ID : Identification

- b. Position the bushing on the outside of the stabilizer bar clamp so as to install it.




EGKSS13A

- c. Let the selection of the bushings be able to be decided by customers.
2. Install the bracket on the bushing.
 3. After tightening the bolts of the bushing bracket temporarily, install the bushing bracket on the opposite side.

REAR SUSPENSION SYSTEM

COMPONANTS


EBFA8A01



TORQUE : Nm (kgf·cm, lbf·ft)

REAR SUSPENSION ARM

COMPONENTS EBAE46E6




CAUTION

The parts marked '*' should be temporarily tightened, and then fully tightened with the vehicle on the ground in unloaded condition.

TORQUE : Nm (kgf-cm, lbf-ft)


REMOVAL EE9CD5CD

1. Remove the bolt (C) fixing the trailing arm (A) to the rear carrier (B).



EHOF210C

2. Remove the bolt (C) fixing the rear suspension arm (A) to the rear carrier (B).




EHOF210D

3. Employ the same manner described above step 1 and step 2 to the other side.
4. After supporting the rear cross member assembly (B) with a jack (A), remove the two cross member fixing bolts (C). Employ the same manner described above to the other side.


CAUTION

The rear cross member assembly (B) is unstable on the jack(A); be careful not to allow it to fall.



EHOF210E

5. Lowering the jack, remove the rear cross member and rear suspension arms as an assembly.
6. Remove the two rear suspension arm-to-cross member bolts (A, B).




EHOF210F

7. Remove the rear suspension arms.

INSTALLATION

ED24684F


1. Installation is in the reverse order of removal.
2. Reassemble the rear suspension arms (C) and the rear cross member (A) as shown below. Make sure that the arrow mark (B) on the rear cross member (A) should place the front face of the vehicle.
Rear suspension arm (C) -to-rear carrier bolts should be temporarily tightened, and then fully tightened with the vehicle on the ground in unloaded condition.



EHOF214A

REAR STRUT ASSEMBLY


COMPONENTS E155657B



TORQUE : Nm (kgf.cm, lbf.ft)


REMOVAL E49456EC

1. Remove the covering self side trim, rear seat belt retractor, luggage side trim and covering self mounting bracket.




EHOF220B

2. Remove the rear strut upper mounting nuts (3).



EHOF220C

3. Remove the wheel and tire.
4. Disconnect the brake hose and wheel speed sensor wiring from the rear strut.
5. Remove the stabilizer bar link.



EHOF240B


6. Remove the strut and carrier mounting bolts(2).

**CAUTION*****Be careful not to drop the rear strut.***

7. Remove the rear strut assembly.

DISASSEMBLY E9DB6DF8

1. Using the special tools (09546-26000 or J38402), compress the coil spring until there is only a little tension on the strut.


**NOTE*****Do not use an impact gun.***

EHOC030A

2. Remove the self-locking nut at the top end of the shock absorber.
3. Remove the insulator, coil spring and dust cover from strut assembly.

INSPECTION E461F02A


1. Check the strut insulator for wear or damage.
2. Check rubber parts for damage or deterioration.
3. Check the coil spring and strut assembly for sagging and deformation.
4. Check the shock absorber for abnormal resistance or unusual sound.



EHOF222A


REASSEMBLY EABD00B6

1. Install the lower spring pad so that the protrusions fit in the holes in the spring lower seat.



EHOF113A

2. Install the dust cover on the shock absorber.
3. Using the special tools (09546-26000 or J38402), compress the coil spring.




EHOC032A

4. After extending the piston rod fully, install the insulator assembly and pipe.

NOTE

Align the D-shaped hole in the spring seat upper assembly with the protrusion of the piston rod.




EHOF113C

5. After seating the lower ends of the coil spring in the lower spring seat grooves correctly, tighten the new self-locking nut temporarily.

**CAUTION**

Replace the self-locking nut with new ones after removal.



EHOF113D

6. Remove the special tools (09546-26000 or J38402).
7. Tighten the self-locking nut to the specified torque.



Tightening torque

40~60 Nm (400~600 kgf·cm, 29~37 lbf·ft)

TRAILING ARM

COMPONANTS EAC6BF7B


[Trailing arm location]



TORQUE : Nm (kgf-cm, lbf-ft)


REMOVAL E565F240

1. Detach the parking brake cable from the rear trailing arm bracket.



EHO230B

2. After loosening the rear trailing arm mounting bolts, remove the trailing arm.
3. Remove the rear suspension arm mounting bolt from the rear axle carrier.




EHO230C

4. After supporting the center of the rear crossmember assembly with a jack, remove the rear crossmember mounting bolts to the body.
5. Remove the rear crossmember and suspension arm.


REPLACEMENT E59DD55F**TRAILING ARM BUSHING**

1. Install the special tool (09551 - 25000) on the trailing arm.



EHO234A


2. Remove the trailing arm bushing.
3. Using the special tool (09551 - 25000), press-fit the rear trailing arm bushing.



EHO234B

**NOTE**


Press-fit the bushing in the same way as shown in the illustration.



EHOF234C


REAR SUSPENSION ARM BUSHING

1. Install the special tools (09545-28100, 09552-25000) on the rear suspension arm.




EHOF234D

2. Remove the rear suspension bushing.
3. Apply soap solution to the new bushing and the rear suspension arm.
4. Using the special tool (09552-25000), press-fit the the bushing.

REAR STABILIZER BAR**COMPONANTS** EFEDA5CD**TORQUE : Nm (kgf·cm, lbf·ft)**

REMOVAL E165A7F2

1. Remove the stabilizer bar link from the rear strut assembly.
2. Remove the rear stabilizer bar mounting brackets.




EHOF240B

3. Remove the stabilizer bar.

INSPECTION EB9BDA05

Check the stabilizer link ball joint rotating torque.



EHOF242A

1. If there is a crack in the dust cover, replace it and add grease.
2. Shake the stabilizer link ball joint stud several times.
3. If the rotating torque is above the upper limit of the standard value, replace the stabilizer link.
4. If the rotating torque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

INSTALLATION EEC5053C


1. Install the bushing on the stabilizer bar.

NOTE

- a. When installing the stabilizer bar, follow the identification color (ID color) as below.

Model	ID color	Outer diameter
GL/GLS	Yellow	16.8mm (0.66 in.)
Sports/Top	Green	17.8mm (0.70 in.)


- b. After matching the bushing in the inside of the white painted part on the stabilizer bar, install the them.



EHOE012A

2. Install the bracket on the bushing.
3. Tighten the components below to the specified torque as follows.

Rear stabilizer bar mounting bracket :
17~26 Nm (170~260 kgf-cm, 13~19 lbf-ft)
Rear stabilizer bar link mounting :
35~45 Nm (350~450 kgf-cm, 26~33 lbf-ft)



EHOF240B

TIRES / WHEELS

DESCRIPTION E35351AF

There are two matching ways about the wheel & tire and front suspension on this vehicle. It follows,

- Standard equipment with 2.0L/2.7L engines :
Normal (Soft) suspension and 16" wheel & tire
- Optional equipment with 2.0L/2.7L engines :
Sports (Hard) suspension and 17" wheel & tire



NOTE

- *The front suspension identification mark can be seen when the front wheel & tire is removed.*
- *The following degeneration in vehicle performance may occur when installing the 17" tires to the 2.0L vehicle models equipped with the normal front suspension.*
The handling may be inferior to the vehicles with 16" tires. However installing 17" tires to the vehicles with hard suspensions does not affect the driving performance.
The 17" tire is for summer season.
Therefore, its performance in snow is inferior to the 16" tire for all seasons.
The 17" tire is directional
An unexpected noise and vibration may occur if tires are not installed correctly according to the rotational direction.
The snow chain with the thickness lower than 10mm is recommended to use on vehicles with 17" tires.

TIRE

FRONT WHEEL ALIGNMENT

EAE3F84C


When using a wheel alignment tester to inspect the front wheel alignment, always position the car on a level surface with the front wheels facing straight ahead. Prior to inspection, make sure that the front suspension and steering system are in normal operating conditions and that the wheels and tires face straight ahead and the tires are inflated to the specified pressure.

TOE-IN

Toe-in (B-A or angle $\alpha + \beta$) is adjusted by turning the tie rod turnbuckles. Toe-in on the left front wheel can be reduced by turning the tie rod toward the rear of the car. Toe-in change is adjusted by turning the tie rods for the right and left wheels simultaneously at the same amount as follows.

Standard value

Toe-in(B-A) mm (in.) : 0 ± 2 mm (0 ± 0.08 in.)



EHOF400A


NOTE

- Toe-in adjustment should be made by turning the right and left tie rods at the same amount.
- When adjusting toe-in, loosen the outer bellows clip to prevent twisting the bellows.
- After the adjustment, tighten the tie rod end lock nuts firmly and reinstall the bellows clip.
- Adjust each toe-in to be the range of ± 1 mm.

Tightening torque

Tie rod end lock nuts :

50~55 Nm (500~550 kgfcm, 37~41 lbf·ft)



EHOF400B

CAMBER


The steering knuckle which is installed with the strut assembly is pre-set to the specified camber at the factory and doesn't need to be adjusted.

Camber : $0^{\circ}13' \pm 30'$

CASTER

Caster is pre-set at the factory and doesn't need to be adjusted. If the caster is not within the standard value, replace the bent or damaged parts.

Caster : $3^{\circ}23' \pm 30'$



EHOF400C

REAR WHEEL ALIGNMENT

TOE-IN

Standard value : 4^{+3}_{-1} mm ($0.16^{+0.12}_{-0.04}$ in.)

EHKB023A

**NOTE**

- Adjust the toe-in by turning the tie rod end of the rear suspension arm..

Left tie rod : Clockwise direction \Rightarrow toe-in

Right tie rod : Clockwise direction \Rightarrow toe-out

A variation of toe by a rotation of the tie rod

: About 6mm (0.6°)


- The cam bolt should be adjusted to a maximum of 90° left or right from the center position.

**CAUTION**


After adjusting the tie rod, tighten both nuts to the specified torque.

Specified torque

50~60 Nm (500~600 kgf·cm, 37~43 lbf·ft)



EHOF402A



EHOF401A

TIRE WEAR

- Measure the tread depth of the tires.

Tread depth of tire [Limit] : 1.6 mm (0.06 in.)

- If the remaining tread depth is less than the limit, replace the tire.

**NOTE**


When the tread depth of the tires is less than 1.6 mm (0.06 in.) the wear indicators will appear.

WHEEL


WHEEL RUNOUT

E495B6F5

1. Jack up the vehicle and support it with jack stands.
2. Measure the wheel runout with a dial indicator as illustrated.



[Axial direction]



[Radial direction]

EHOF403A

3. Replace the wheel if the wheel runout exceeds the limit.

Wheel runout [Limit]

Steel wheel

Radial 0.6mm (0.028 in.) : (Average of LH & RH)

Axial 1.0mm (0.039 in.)

Aluminum wheel

Radial 0.3mm (0.012 in.)

Axial 0.3mm (0.012 in.)

LH : Left Hand side, RH : Right Hand side

TIGHTENING WHEEL NUT


1. Tightening torque
Steel and aluminum alloy wheel

Specified torque

90~110 Nm (900~1,100 kgf·cm, 65~80 lbf·ft)


**CAUTION**

When using an impact gun, final tightening torque should be checked using a torque wrench.



EHOF404A

2. Tightening order
Check the torque again after tightening the wheel nuts diagonally.



KFW6020A

WHEEL ROTATION

Rotate the tires in the pattern illustrated.


**CAUTION**

When rotating the 215/45 R17 tires, ensure to follow the "ROTATION" direction marked on the side-wall of tires.

When rotating the tires of the left and right, separate the wheel from the tire and then re-assemble them.


CHECKING FOR PULL AND WANDER

1. If the steering pulls to one side, rotate the tires according to the following wheel rotation procedure.
 - a. Rotate the front right and front left tires, and perform a road test in order to confirm vehicle stability.




EHDA854B

- b. If the steering pulls to the opposite side, rotate the front and rear tires, and perform a road test again.




EHDA854C

- c. If the steering continues to pull to one side, rotate the front right and left tires again, and perform a road test.



EHDA854B

- d. If the steering continues to pull to the opposite side, replace the front wheels with new ones.



EHDA854D

2. On some vehicles which drift or pull to the right only, the following procedure may be applied for fixing.
 - a. Adjust tire pressure as recommended below (4 tire) prior to conducting road test.

Tire inflation pressure : 2.1 kgf/cm² (30 psi)
215/45 R 17 tire only : 2.2 kgf/cm² (32 psi)

- b. To eliminate the pulling, rotate the front tires and test drive the vehicle to see if the pulling returns.
 - c. If a vehicle still exhibits the pulling to the right, replace the right front strut insulator with the re-designed new part (Part No. 54610-2C000A) which increases the caster angle. (see page SS-11)

**NOTE**

- This procedure applies to the vehicle pulls to the right only.
- Confirm the direction of the vehicle pulling by road testing prior to performing the repair procedure.
- If 'Michelin' tires are installed, do not rotate the tires because they are directional. Replace the right front strut insulator only.