

|   |         |
|---|---------|
| SERVICE MANUAL  |         |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |         |
| GROUP   |         |
| Brake Systems   | General |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## SPECIFICATIONS

### Master cylinder

|                            |                      |
|----------------------------|----------------------|
| Type                       | Tandem               |
| I.D.                       | 22.22 mm (1.875 in.) |
| Fluid level warning sensor | Provided             |

### Brake booster

|                                     |                         |                                     |
|-------------------------------------|-------------------------|-------------------------------------|
|                                     | RHD                     | LHD                                 |
| Type                                | Vacuum                  |                                     |
| Effective dia.                      | 240.4 mm<br>(9.464 in.) | 190 (7.480)+215 (8.465) mm<br>(in.) |
| Boosting ratio<br>(at stroke 10 mm) | 4.5 : 1                 | 6.0 : 1                             |

### Proportioning valve

|                               |                               |
|-------------------------------|-------------------------------|
| Cut-in pressure (Split point) | 3.92 MPa (40 kg/cm2, 569 psi) |
| Decompression ratio           | 3.7 : 1                       |

### Front brake

|                |                                    |
|----------------|------------------------------------|
| Type           | Floating type with ventilated disc |
| Disc O.D.      | 257 mm (10.118 in.)                |
| Disc thickness | 22 mm (0.866 in.)                  |
| Pad thickness  | 9 mm (0.354 in.)                   |
| Cylinder I.D.  | 54 mm (2.126 in.)                  |

### Rear drum brake

|                        |                       |
|------------------------|-----------------------|
| Type                   | Leading-trailing drum |
| Drum I.D.              | 203.2 mm (8.0 in.)    |
| Brake lining thickness | 4.05 mm (0.159 in.)   |
| Cylinder I.D           | 19.05 mm (0.75in.)    |
| Clearance adjustment   | Automatic             |

### Rear disc brake

|                |                     |
|----------------|---------------------|
| Type           | Ventilated disc     |
| Disc O.D       | 258 mm (10.157 in.) |
| Disc Thickness | 10 mm (0.354 in.)   |
| Pad Thickness  | 9 mm (0.354 in.)    |

**Parking brake**

|                   |  |
|-------------------|--|
| Type              | Mechanical brake acting on rear wheels |
| Braking type      | Lever type (cam shape)                 |
| Cable arrangement | V type                                 |

**ABSCM (ABS Control Module)**

|                             |                 |
|-----------------------------|-----------------|
| Operating voltage range     | 9.0-16.2V       |
| Power consumption           | 150 mA or below |
| Control fuse                | 10A             |
| Operating temperature range | -40° to +80°C   |

**Service Reminder Indicator**

|                                 |      |
|---------------------------------|------|
| Power consumption               | 1.2W |
| Service Reminder Indicator fuse | 10A  |

**Modulator**

|                             |                |
|-----------------------------|----------------|
| Operating voltage range     | 9.0-16.2V      |
| Rated voltage               | 12A            |
| Motor pump fuse             | 30A            |
| Solenoid fuse               | 20A            |
| Operating temperature range | -40°C to 120°C |

|   |         |
|---|---------|
| <b>SERVICE MANUAL</b>                                       |         |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |         |
| <b>GROUP</b>  |         |
| Brake Systems   | General |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## TIGHTENING TORQUE

| I   | Nm    | Kg.cm   | lb.ft |
|---|-------|---------|-------|
| Master cylinder booster mounting nut            | 8-12  | 80-120  | 6-9   |
| Brake booster mounting nut                      | 8-12  | 80-120  | 6-9   |
| Brake booster vacuum hose fitting to surge tank | 8-12  | 80-120  | 6-9   |
| Bleeder screw                                   | 7-13  | 70-130  | 5-9.5 |
| Brake tube flare nut, brake hose                | 13-17 | 130-170 | 9-12  |
| Proportioning valve mounting nut                | 8-12  | 80-120  | 6-9   |
| Caliper guide rod bolt                          | 22-32 | 220-320 | 16-24 |
| Caliper pin bolt                                | 35-45 | 350-450 | 26-33 |
| Caliper assembly to knuckle                     | 69-85 | 690-850 | 44-63 |
| Brake hose to front caliper                     | 25-30 | 250-300 | 18-22 |
| Backing plate mounting bolt                     | 50-60 | 500-600 | 37-44 |
| Sensor mounting bolt on the brake plate (Front) | 7-11  | 70-110  | 5-8   |
| Sensor mounting bolt on the brake plate (Rear)  | 17-26 | 170-260 | 12-19 |
| Hydraulic unit mounting bolt                    | 17-26 | 170-260 | 12-19 |
| Hydraulic unit mounting bracket bolt            | 17-26 | 170-260 | 12-19 |
| Six brake tubes on the Hydraulic unit           | 13-17 | 130-170 | 9-12  |

|   |         |
|---|---------|
| <b>SERVICE MANUAL</b>                                       |         |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |         |
| <b>GROUP</b>  |         |
| Brake Systems   | General |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## TROUBLESHOOTING

| Symptom  | Probable cause  | Remedy              |
|--|---|---------------------|
| Noise or vibration when brakes are applied                     | Backing plate or caliper improperly mounted             | Correct             |
|  | Loose backing plate or caliper mounting bolts           | Retighten           |
|  | Unevenly worn or cracked brake drum or brake disc       | Replace             |
|  | Foreign material in brake drum                          | Clean               |
|  | Seized pad or lining contact surface                    | Replace             |
|  | Excessive caliper to pad assembly clearance             | Correct             |
|  | Uneven pad contact                                      | Correct             |
|  | Lack of lubrication in sliding parts                    | Lubricate           |
|  | Loose suspension parts                                  | Retighten           |
| Vehicle pulls to one side when brakes are applied              | Difference in left and right tire inflation pressure    | Adjust              |
|  | Improper front wheel alignment                          | Adjust              |
|  | Inadequate contact of pad or lining                     | Correct             |
|  | Grease or oil on pad or lining surface                  | Replace             |
|  | Drum eccentricity or uneven wear                        | Replace             |
|  | Incorrect wheel cylinder installation                   | Correct             |
|  | Auto adjuster malfunction                               | Correct             |
| Insufficient braking power                                     | Low or contaminated brake fluid                         | Replenish or change |
|  | Air in brake system                                     | Bleed the system    |
|  | Brake booster malfunction                               | Correct             |
|  | Inadequate contact of pad or lining                     | Correct             |
|  | Grease or oil on pad surface                            | Replace             |
|  | Auto adjuster malfunction                               | Correct             |
|  | Overheated brake rotor due to dragging of pad or lining | Correct             |
|  | Restricted brake line                                   | Correct             |
|  | Proportioning valve malfunction                         | Replace             |
| Increased pedal stroke (Reduced pedal to floorboard clearance) | Air in brake system                                     | Bleed the system    |
|  | Brake fluid leaks                                       | Correct             |

|                                     |   |  |
|-------------------------------------|---|--|
|                                     | Auto adjuster malfunction                                     | Correct  |
|                                     | Excessive push rod to master cylinder clearance               | Adjust   |
| Brake drag                          | Incomplete release of parking brake                           | Correct  |
|                                     | Incorrect parking brake adjustment                            | Adjust   |
|                                     | Weak brake pedal return spring                                | Replace  |
|                                     | Restricted master cylinder return pod                         | Correct  |
|                                     | Broken rear drum brake shoe return spring                     | Replace  |
|                                     | Lack of lubrication in sliding pads                           | Lubricate  |
|                                     | Defective master cylinder check valve or piston return spring | Replace  |
|                                     | Insufficient push rod to master cylinder clearance            | Replace  |
| Insufficient parking brake function | Worn brake lining   | Replace  |
|                                     | Grease or oil on lining surface                               | Replace  |
|                                     | Parking brake cable sticking                                  | Replace  |
|                                     | Auto adjuster malfunction                                     | Correct  |
|                                     | Excessive parking brake lever stroke                          | Adjust the parking brake lever stroke or check the parking brake cable routing |

|   |         |
|---|---------|
| <b>SERVICE MANUAL</b>                                       |         |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |         |
| <b>GROUP</b>  |         |
| Brake Systems   | General |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## SERVICE STANDARD

### Standard value

|   |                                 |
|---|---------------------------------|
| Brake pedal height  | 190.1 mm<br>(7.485 in.)         |
| Stop lamp switch outer case to pedal stopper clearance                                | 0.5-1.0 mm<br>(0.020-0.040 in.) |
| Brake pedal free play   | 3-8 mm (0.118-0.315 in.)        |
| Brake pedal to floorboard clearance   | 65 mm (2.56 in.) or more        |
| Booster push rod to master cylinder piston clearance                                  | 0 (at 500 mmHg vacuum)          |
| Parking brake lever stroke when lever assembly is pulled with 196N (20kg, 441b force) | 7-8 clicks                      |







### Service limit






|                                    |                          |
|------------------------------------|--------------------------|
| Front disc brake pad thickness     | 2.0 mm (0.079 in.)       |
| Front disc thickness (minimum)     | 20 mm (0.787 in.)        |
| Front disc runout                  | 0.04 mm<br>( 0.002 in.). |
| Drum brake lining thickness        | 1.5 mm<br>(0.031 in.)    |
| Brake drum I.D. (maximum)          | 205.2 mm<br>(8.079 in.)  |
| Wheel cylinder to piston clearance | 0.15 mm<br>(0.006 in.)   |

|   |         |
|---|---------|
| <b>SERVICE MANUAL</b>                                       |         |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |         |
| <b>GROUP</b>  |         |
| Brake Systems   | General |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## SPECIAL TOOLS

| Tool (Number and Name)                    | Illustration  | Use  |
|---|---|--|
| 09581 - 11000<br>Piston expander          |    | Pushing back of the front disc brake piston              |
| 09580-34000<br>Rear brake piston adjuster |   | Removal and installation of the rear brake piston        |
| 09500-21000<br>Bar                        |  | Removal of front wheel bearing                           |
| 09517-21000<br>Hub bearing remover        |  | Removal of front wheel bearing<br>(Use with 09500-21000) |
| 09216-21300<br>Hub bearing installer      |  | Installation of front wheel bearing                      |
| 09495-33000<br>Puller                     |  | Removal of the front wheel bearing inner race            |
|   |   |  |


|  |   |   |
|--|---|---|
| <p>09517-21500<br/>Front hub remover and installer</p> |    | <p>Removal &amp; installation of front hub<br/>(Use with 09517-29000)</p>                                 |
| <p>09517-29000<br/>Knuckle arm bridge</p>              |    | <p>Removal of the front hub<br/>(Use with 09517-21500)</p>  |
| <p>09532-11600<br/>Pre-load socket</p>                 |    | <p>Measuring of front wheel bearing preload<br/>(Use with 0917-21500, 30 mm socket and torque wrench)</p> |
| <p>09526-11001<br/>Axle shaft puller</p>               |   | <p>Removal of the drive shaft front hub</p>   |
| <p>09568-34000<br/>Ball joint remover</p>              |  | <p>Removal of the front lower arm ball joint and tie rod end ball joint</p>                               |



|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## COMPONENTS




The Anti-Lock Brake System (ABS) controls the hydraulic brake pressure of all four wheels during sudden braking and braking on hazardous road surfaces, preventing the wheels from locking. The ABS provides the following benefits:

It enables steering around obstacles with a greater degree of certainty, even during panic braking.

It enables stopping during panic braking while allowing stability and steerability to a minimum, even on curves.

In case a malfunction occurs, a diagnosis function and fail-safe system have been included for serviceability.

## HYDRAULIC SYSTEM DIAGRAM



|   |                        |
|---|------------------------|
| SERVICE MANUAL  |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| GROUP   |                        |
| Brake Systems   | Anti-lock Brake System |


Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

SYSTEM DIAGNOSIS

INDICATOR CHECK


When the ignition switch is turned on, check that the ABS SRI goes ON for 6 seconds.

If the SRI is not illuminated immediately after ignition on, the ABS fail safe relay may be at fault.



SRI CODE CHECK


With the ignition switch turned ON and "L" terminal of data link connector shorted to ground, diagnostic trouble code No. can be checked, if faults are detected, with reading of SRI lamp flash.



Ground the "L" terminal (Pin No. 15) of data link connector with extension wire, otherwise fault code cannot be accessed.

Turn the ignition switch ON.

SRI lamp will illuminates for 2 seconds and followed by 3 seconds illumination meaning "Check-in" signal then read the following "Diagnostic trouble code".



The first digit of Diagnostic trouble code is determined by the number of long flashes (1.5 sec.) and after the following 2 seconds break, the second digit is determined by the number of short flashes (0.5 sec.).

Once the SRI lamp flashing is completed, next active trouble code or history trouble code stored at ABSCM will be followed after 3 sec. break while the "L" terminal is grounded or the ignition switch is ON.


Diagnostic Trouble code will be retained in the ABSCM until the ignition has been switched ON and the vehicle speed exceeded 8km/h 20 times.

|                              | SRI lamp flash pattern | Remarks   |
|------------------------------|------------------------|---|
| L-line ground OFF            |                        | <ul style="list-style-type: none"><li>o System normal or fault code is stored at ABSCM</li><li>o ABSCM has active fault</li></ul>           |
| L-line (Pin No. 15) Grounded |                        | <ul style="list-style-type: none"><li>o System Normal</li></ul>   |
|                              |                        | <ul style="list-style-type: none"><li>o Active fault No.22 flashes after check-in period and followed by history fault code No.23</li></ul> |

CONNECTOR CHECK

Remove the battery negative (-) terminal.










Disconnect the connectors and check the terminals follow the troubleshooting procedure.























**NOTE**











When you check terminals, be sure to use enough small pin which is not damage t the connector terminals.

**DIAGNOSTIC TROUBLE CODE CHART**


| Diagnostic trouble code No. | DISPLAY ON SCAN TOOL             |   | Diagnosis item        | Check Item   |
|-----------------------------|----------------------------------|---|-----------------------|--|
|                             | SRI lamp flash pattern           |   |                       |  |
| 19                          | DEFECTIVE TONE WHEEL             |   | CHECK THE TONE WHEELS | Check for a defective tone wheel on a wheel.                                     |
|                             | ON<br>OFF                        |    |                       |  |
| 21                          | LF SOLENOID CIRCUIT - SHORT BATT |   | LEFT FRONT SOLENOID   | Detection for short circuit to +12 Volt for the left front solenoid.             |
|                             | ON<br>OFF                        |    |                       |  |
| 22                          | LF SOLENOID CIRCUIT - SHORT GND  |   | LEFT FRONT SOLENOID   | Detection for open circuit or short circuit to GND for the left front solenoid.  |
|                             | ON<br>OFF                        |    |                       |  |
| 23                          | RF SOLENOID CIRCUIT - SHORT BATT |   | RIGHT FRONT SOLENOID  | Detection for short circuit to +12 Volt for the right front solenoid.            |
|                             | ON<br>OFF                        |  |                       |  |
| 24                          | RF SOLENOID CIRCUIT - SHORT GND  |   | RIGHT FRONT SOLENOID  | Detection for open circuit or short circuit to GND for the right front solenoid. |
|                             | ON<br>OFF                        |  |                       |  |
| 25                          | LR SOLENOID CIRCUIT - SHORT BATT |   | LEFT REAR SOLENOID    | Detection for short circuit to +12 Volt for the left rear solenoid.              |
|                             | ON<br>OFF                        |  |                       |  |
| 26                          | LR SOLENOID CIRCUIT - SHORT GND  |   | LEFT REAR SOLENOID    | Detection for open circuit or short circuit to GND for the left rear solenoid.   |
|                             | ON<br>OFF                        |  |                       |  |
| 27                          | RR SOLENOID CIRCUIT - SHORT BATT |   | RIGHT REAR SOLENOID   | Detection for short circuit to +12 Volt for the right rear solenoid.             |
|                             | ON<br>OFF                        |  |                       |  |
| 28                          | RR SOLENOID CIRCUIT - SHORT GND  |   | RIGHT REAR SOLENOID   | Detection for open circuit or short circuit to GND for the right rear solenoid.  |
|                             | ON<br>OFF                        |  |                       |  |

| Diagnostic trouble code No. | DISPLAY ON SCAN TOOL            |   | Diagnosis item      | Check Item   |
|-----------------------------|---------------------------------|---|---------------------|--|
|                             | SRI lamp flash pattern          |   |                     |  |
| 31                          | LF WHEEL SPEED SENSOR AIR GAP   |   | LEFT FRONT SENSOR   | Detection for the air gap of the tone wheel. This detection will be activated if all wheel speeds are zero and the ABS-function is not active. |
|                             | ON<br>OFF                       |    |                     |  |
| 32                          | RF WHEEL SPEED SENSOR AIR GAP   |   | RIGHT FRONT SENSOR  | Detection for the air gap of the tone wheel. This detection will be activated if all wheel speeds are zero and the ABS-function is not active. |
|                             | ON<br>OFF                       |    |                     |  |
| 33                          | LR WHEEL SPEED SENSOR AIR GAP   |   | LEFT REAR SENSOR    | Detection for the air gap of the tone wheel. This detection will be activated if all wheel speeds are zero and the ABS-function is not active. |
|                             | ON<br>OFF                       |    |                     |  |
| 34                          | RR WHEEL SPEED SENSOR AIR GAP   |   | RIGHT REAR SENSOR   | Detection for the air gap of the tone wheel. This detection will be activated if all wheel speeds are zero and the ABS-function is not active. |
|                             | ON<br>OFF                       |    |                     |  |
| 35                          | MOTOR PUMP                      |   | MOTOR PUMP          | Check for faulty or seized up of motor pump.   |
|                             | ON<br>OFF                       |   |                     |  |
| 36                          | MOTOR PUMP RELAY - SHORT GND    |   | MOTOR RELAY CIRCUIT | Detection for a open circuit or a short circuit to GND from the motor pump relay.  |
|                             | ON<br>OFF                       |  |                     |  |
| 37                          | MOTOR PUMP RELAY - SHORT BATT   |   | MOTOR RELAY CIRCUIT | Detection for a short circuit to +12 Volt from the motor pump relay.   |
|                             | ON<br>OFF                       |  |                     |  |
| 38                          | MOTOR PUMP CIRCUIT - SHORT BATT |   | PUMP MOTOR          | Detection for a short circuit at the motor pump  |
|                             | ON<br>OFF                       |  |                     |  |
| 39                          | MOTOR PUMP CIRCUIT - SHORT GND  |   | PUMP MOTOR          | Detection for a short circuit to GND at the motor pump   |
|                             | ON<br>OFF                       |  |                     |  |
| 41                          | FAIL SAFE RELAY CIRCUIT - SHORT |   | FAIL SAFE RELAY     | Fail safe relay contacts are short circuit.  |
|                             | ON<br>OFF                       |  |                     |  |

| Diagnostic trouble code No. | DISPLAY ON SCAN TOOL           |   | Diagnosis item                   | Check Item  |
|-----------------------------|--------------------------------|---|----------------------------------|---|
|                             | SRI lamp flash pattern         |   |                                  |   |
| 42                          | FAIL SAFE RELAY CIRCUIT - OPEN |   | FAIL SAFE RELAY                  | Fail safe relay contacts are open circuit   |
|                             | ON                             |    |                                  |   |
| 43                          | FAIL SAFE RELAY COIL           |   | FAIL SAFE RELAY COIL             | The current from the fail safe relay is too high or too low                       |
|                             | ON                             |    |                                  |   |
| 44                          | ABS SRI CIRCUIT - SHORT GND    |   | SERVICE REMINDER INDICATOR       | Detection of a short circuit of the Service Reminder Indicator (Permanently on)   |
|                             | ON                             |    |                                  |   |
| 45                          | ABS SRI DIODE - OPEN           |   | SERVICE REMINDER INDICATOR DIODE | Detection for a open circuit of the diode for the Service Reminder Indicator ABS. |
|                             | ON                             |    |                                  |   |
| 54                          | ABS SRI CIRCUIT - SHORT BATT   |   | SERVICE REMINDER INDICATOR       | Detection for a short circuit to +12V of the Service Reminder Indicator           |
|                             | ON                             |   |                                  |   |
| 55                          | ABS SRI CIRCUIT - OPEN         |   | SERVICE REMINDER INDICATOR       | Detection for a open circuit of the Service Reminder Indicator ABS.               |
|                             | ON                             |  |                                  |   |
| 56                          | BATTERY VOLTAGE - LOW          |   | BATTERY VOLTAGE                  | Battery voltage out of the function range (Under voltage) for the system.         |
|                             | ON                             |  |                                  |   |
| 57                          | BATTERY VOLTAGE - HIGH         |   | BATTERY VOLTAGE                  | Battery voltage out of the function range (Over voltage) for the system.          |
|                             | ON                             |  |                                  |   |
| 62                          | LF WHEEL SENSOR - CIRCUIT OPEN |   | LEFT FRONT SENSOR CIRCUIT        | Sensor open circuit or short to 12 Volt detection for the left front wheel        |
|                             | ON                             |  |                                  |   |
| 63                          | RF WHEEL SENSOR - CIRCUIT OPEN |   | RIGHT FRONT SENSOR CIRCUIT       | Sensor open circuit or short to 12 Volt detection for the right front wheel.      |
|                             | ON                             |  |                                  |   |

| Diagnostic trouble code No. | DISPLAY ON SCAN TOOL              |   | Diagnosis item                   | Check item   |
|-----------------------------|-----------------------------------|---|----------------------------------|--|
|                             | SRI lamp flash pattern            |   |                                  |  |
| 64                          | LR WHEEL SENSOR<br>- CIRCUIT OPEN |   | LEFT REAR<br>SENSOR<br>CIRCUIT   | Sensor open circuit or short to 12 Volt<br>detection for the left rear wheel.                          |
|                             | ON                                |    |                                  |  |
| 65                          | RR WHEEL SENSOR<br>- CIRCUIT OPEN |   | RIGHT REAR<br>SENSOR<br>CIRCUIT  | Sensor open circuit or short to 12 Volt<br>detection for the right rear wheel.                         |
|                             | ON                                |    |                                  |  |
| 66                          | LF WHEEL SENSOR<br>- SHORT GND    |   | LEFT FRONT<br>SENSOR<br>CIRCUIT  | Sensor short to GND detection for the left<br>front wheel  |
|                             | ON                                |    |                                  |  |
| 67                          | RF WHEEL SENSOR<br>- SHORT GND    |   | RIGHT FRONT<br>SENSOR<br>CIRCUIT | Sensor short to GND detection for the<br>right front wheel.  |
|                             | ON                                |    |                                  |  |
| 68                          | LR WHEEL SENSOR<br>- SHORT GND    |   | LEFT REAR<br>SENSOR<br>CIRCUIT   | Sensor short to GND detection for the left<br>rear wheel.  |
|                             | ON                                |   |                                  |  |
| 69                          | RR WHEEL SENSOR<br>- SHORT GND    |   | RIGHT REAR<br>SENSOR<br>CIRCUIT  | Sensor short to GND detection for the<br>right rear wheel.   |
|                             | ON                                |  |                                  |  |
| 71                          | LF TONE WHEEL<br>TOOTH MISSING    |   | LEFT FRONT<br>TONE WHEEL         | Detection for missing teeth on the tone<br>wheel or speed jumps over-100g on the<br>left front wheel.  |
|                             | ON                                |  |                                  |  |
| 72                          | RF TONE WHEEL<br>TOOTH MISSING    |   | RIGHT FRONT<br>TONE WHEEL        | Detection for missing teeth on the tone<br>wheel or speed jumps over-100g on the<br>right front wheel. |
|                             | ON                                |  |                                  |  |
| 73                          | LR TONE WHEEL TOOTH MISSING       |   | LEFT REAR<br>TONE WHEEL          | Detection for missing teeth on the tone<br>wheel or speed jumps over-100g on the<br>left rear wheel.   |
|                             | ON                                |  |                                  |  |
| 74                          | RR TONE WHEEL TOOTH MISSING       |   | RIGHT REAR<br>TONE WHEEL         | Detection for missing teeth on the tone<br>wheel or speed jumps over -100g on the<br>right rear wheel. |
|                             | ON                                |  |                                  |  |



| Diagnostic trouble code No. | DISPLAY ON SCAN TOOL  | Diagnosis item | Check item                                  |
|-----------------------------|---|----------------|---|
|                             | SRI lamp flash pattern  |                |   |
| 77                          | ABS CONTROL MODULE  | ABSCM ERROR    | Check for ABSCM (ABS Control module) error. |
|                             | ON <br>OFF |                |   |


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

**DTC - 56, 57**


**POWER SOURCE VOLTAGE**

Detection of battery out of the function range for the system.




| DTC Code | DISPLAY ON SCAN TOOL   | Symptom                                       | Possible cause  |
|----------|------------------------|---|---|
| 56       | BATTERY VOLTAGE - LOW  | ABSCM power supply voltage is 8.9V or below   | <ul style="list-style-type: none"> <li>• Battery</li> <li>• Charging circuit</li> <li>• Harness connector between battery and ABSCM, ABSCM and body ground</li> </ul> |
| 57       | BATTERY VOLTAGE - HIGH | ABSCM power supply voltage is 16.2V or higher |   |

**WIRING DIAGRAM**



## INSPECTION PROCEDURE

Check the ABSCM fuse.

|   |   |
|---|---|
|  | <p>1. Remove the FUSE 11 and Inspect in the DASH FUSE BOX.</p> <p><b>LIMIT</b> Continuity</p> |
| <p><b>OK</b> → <b>2</b></p>   | <p><b>NG</b> → Replace Fuse 11 then recheck.</p>  |

Check voltage between Battery (+) and GND of ABSCM connector.

M60 ABS/CM harness  
side connector

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |



1. Remove battery negative(-) terminal.
2. Remove the ABS/CM and disconnect the connector.
3. Connect battery negative(-) terminal.
4. Turn ignition switch to ON position.
5. Measure the supply voltage between terminals 50 and 27.

**LIMIT** 9.5V - 14.2V


**OK** → Connect the ABS/CM and re-check the diagnostic code. If code 56, 57 displayed, check for the ABS/CM poor connection.

**NG** → **3**

Check continuity between the ABS/CM connector GND and Body GND.

M60 ABS/CM harness  
side connector

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |



1. Turn the ignition switch to the LOCK position.
2. Disconnect ABS/CM connector.
3. Measure the ground connection between terminal 27 and body ground, terminal 26 and body ground, terminals 51 and body ground.

**LIMIT** 0.5 Ω or below

**OK** → Check for an open between the harness and the connector between the ABS/CM and the battery

**NG** →  

1. Check ground connection for corrosion and loosening
2. Repair harness or connector.


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## ABS SRI (SERVICE REMINDER INDICATOR) CIRCUIT


If trouble occurs, the ABSCM lights the ABS-SRI while at the same time terminating ABS operation. At this time, the ABSCM records a diagnostic code in memory.

If the ABSCM detects a fault in the Anti-Lock Brake System, the ABSCM turns the ABS SRI on and disables the ABS. At the same time a trouble code is stored in the ABSCM memory.



| DTC Code | DISPLAY ON SCAN TOOL         | Symptom                                    | Possible Cause  |
|----------|------------------------------|--|---|
| 44       | ABS SRI CIRCUIT - SHORT GND  | Service Reminder Indicator short to ground | <ul style="list-style-type: none"> <li>• Service Reminder Indicator</li> <li>• Box (Fail safe Relay)</li> <li>• Fuse</li> </ul> |
| 45       | ABS SRI DIODE - OPEN         | Service Reminder Indicator diode not OK    |   |
| 46       | ABS SRI CIRCUIT - SHORT BATT | Service Reminder Indicator short to 12V    |   |
| 47       | ABS SRI CIRCUIT - OPEN       | Service Reminder Indicator open circuit    |   |

## WIRING DIAGRAM




## INSPECTION PROCEDURE

Check the ABS Service Reminder Indicator circuit without Relay-Box

|  |  |
|--|--|
| <div style="text-align: center;"> <div style="border: 2px solid black; padding: 5px; font-size: 24px; font-weight: bold;">ABS</div> <p>LAMP OFF</p> </div>   | <ol style="list-style-type: none"> <li>1. Disconnect the battery negative terminal</li> <li>2. Disconnect the ABSCM connector</li> <li>3. Remove the ABS Relay-Box connector, while ignition switch "LOCK".</li> <li>4. Connect the battery negative (-) terminal</li> <li>5. Turn ignition switch to ON position</li> <li>6. Check the SRI condition.</li> </ol> <div style="border: 1px solid black; padding: 5px; display: inline-block;"> <b>LIMIT</b> Lamp OFF         </div> |
| <div style="display: flex; align-items: center;"> <div style="font-size: 24px; font-weight: bold; margin-right: 10px;">OK →</div> <div style="border: 1px solid black; padding: 5px; font-size: 24px; font-weight: bold;">3</div> </div> | <div style="display: flex; align-items: center;"> <div style="font-size: 24px; font-weight: bold; margin-right: 10px;">NG →</div> <div>Goto step 4</div> </div>  |

Check the ABS Relay-Box harness



M62 Relay Box harness  
side connector


1. Turn ignition switch to "LOCK" position.
2. Disconnect the Relay Box connector.
3. Check the continuity between the Relay-Box harness terminal 7 and body ground.

**LIMIT** No continuity

**OK →** 5

**NG →** Repair the harness

Check the ABSCM connector harness



M60 ABSCM harness  
side connector

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |

1. Disconnect the battery negative terminal.
2. Disconnect the ABSCM connector.
3. Check the continuity between ABSCM connector harness pin No.17 and body ground.

**LIMIT** No continuity

**OK →** Re-connect the ABSCM and recheck from step 1.

**NG →** Repair the harness

Check the ABS SRI Circuit

Ignition ON

M62 Relay Box connector

M62 Relay Box connector

1. Turn ignition switch to "LOCK" position.
2. Remove the ABS Relay box connector and the ABSCM connector.
3. Ground Relay box terminal 2 and turn the ignition ON.

**LIMIT** SRI ON

4. Turn ignition switch to "LOCK" position.
5. Check the continuity between terminal 6 and body ground.

**LIMIT** Continuity

**OK** → **7**

**NG** → Repair the harness

Check the ABS-Relay Box (Fail safe relay)

M62 Relay Box connector

E58 Relay Box harness side connector

B+

E58 Relay Box harness side connector

M62 Relay Box connector

1. Turn ignition switch to "LOCK" position.
2. Remove the ABS Relay Box connector.
3. Check continuity between each terminal of the Relay box.

**LIMIT**

|                        |               |
|------------------------|---------------|
| Terminals 3, 6         | Continuity    |
| Terminals 2, 7         | Continuity    |
| Terminals M62-4, E58-1 | No continuity |

4. Apply battery voltage between terminals 2 and 7.

**Caution**  
**Never attempt to continue 2 sec. or more**

5. Check for continuity.



**LIMIT**

|                        |               |
|------------------------|---------------|
| Terminals 6, 1         | No continuity |
| Terminals M62-1, E58-1 | Continuity    |

**OK** → Re-connect the ABSCM and recheck from step 1.

Check the Fail safe relay





1. Turn ignition switch to "LOCK" position.
2. Remove the Relay-box cover.
3. Remove the Fail-safe relay.
4. Check cotiriuity beMeen terminals as foUows.

**f LfMff f**

|                     |               |
|---------------------|---------------|
| Terminals 2 and 4   | Continuity    |
| Terminals 1 and 5   | No continuity |
| Termirials. 3 and 5 | Continuity    |

5. Apply battery voltage between terminal 2 and 4.  
**Caution**  
**Never attempt to continue 2 sec. or more.**
6. Check continuity between 1erminais asfollows.

**(i:1 | |**

|                      |               |
|----------------------|---------------|
| Terminals t and 5    | Continuity    |
| Terminas, s. 3 and 5 | No continuity |

**QK-+** Re-connect the ABS-Relay arid recheck.

**NG** Replace the Fail safe relay


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## CIRCUIT INSPECTION (ABS RELAY BOX CIRCUIT - FAIL SAFE RELAY)

Fail safe relay supplies battery voltage to the modulator. After the ignition switch is turned ON, the relay goes on, if the initial check is good.

If a problem occurs in the ABS system, the ABSCM disables the relay and the ABS is disabled.



59JF0600

| DTC Code | DISPLAY ON SCAN TOOL            | Symptom   | Possible Cause  |
|----------|---------------------------------|---|---|
| 41       | FAIL SAFE RELAY CIRCUIT - SHORT | Fail safe relay not set<br>activeContact signal stay close  | <ul style="list-style-type: none"> <li>• Fail safe relay</li> <li>• Harness between Relay box and ABSCM</li> <li>• ABSCM</li> </ul>   |
| 42       | FAIL SAFE RELAY CIRCUIT - OPEN  | Fail safe relay set<br>activeContact signal stay not closed | <ul style="list-style-type: none"> <li>• Fail safe Relay</li> <li>• Harness between Relay box and Power source</li> <li>• Harness between Relay box and ABSCM</li> <li>• ABSCM</li> </ul> |
| 43       | FAIL SAFE RELAY COIL            | Fail safe relay coil not OK                                 |   |

## WIRING DIAGRAM



**M62 Relay Box connector**

**E58 Relay Box harness side connector**

**M62 Relay Box connector**

**E58 Relay Box harness side connector**

1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABS Relay Box connector.
3. Check for continuity between as follows.
 

| LIMIT                 |               |
|-----------------------|---------------|
| Terminal 5,6          | Continuity    |
| Terminal M62-5, E58-1 | No continuity |
| Terminal 2,7          | Continuity    |
4. Apply battery voltage between terminal 2 and 7.
 


**Caution**  
Never attempt to continue 2 sec. or more
5. Check for continuity as follows.
 

| LIMIT                 |               |
|-----------------------|---------------|
| Terminal 5,6          | No continuity |
| Terminal M62-5, E58-1 | Continuity    |

**OK → 4**

**NG → 3**


Check the Fail safe relay



1. Turn ignition switch to "LOCK" position.
2. Remove the Relay-box cover.
3. Remove the Fail-safe relay.
4. Check for continuity between terminals as follows.

**LIMIT**

|                   |               |
|-------------------|---------------|
| Terminals 2 and 4 | Continuity    |
| Terminals 1 and 5 | Noncontinuity |
| Terminals 3 and 5 | Continuity    |



5. Apply battery voltage between terminals 2 and 4.

**Caution**

**Never attempt to continue 2 sec. or more.**

6. Check for continuity between terminals as follows.

**LIMIT**

|                   |               |
|-------------------|---------------|
| Terminals 1 and 5 | Continuity    |
| Terminals 3 and 5 | No continuity |

**OK →**

Re-connect fail-safe relay and recheck from step 1.


**NG →**

Replace the Fail safe relay

Check the ABSCM harness


M60 ABSCM harness  
5100 connector

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |




M60 ABSCM hB1meS\$  
side conn-e,ctor

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |



M60ABSGM harness  
5100 connector

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |



ON

Ignition

1. Turn ignition switch to "LOG K" position.
2. Connect the fail safe relay.
3. Disconnect the ABSCM connector.
4. Measure the resistance between terminals 43 and 27.

**UMIF** .0 :LI or below

5. Measure the resistance between terminals 28 and 50.

**LIMIT** 20.2a n

6. Ground terminal 28.
7. Turn ignition switch to "ON" position .  
Caution  
**Never** attempt to continue 2 sec. or more.

B. Measure the voltage between terminal 43 and 27 .

**LIMIT** 9.0-14.2 V

**OK-+** Re-connect the ABSCM and recheck from step 1.

**NG** Repair the harness

|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |


Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## CIRCUIT INSPECTION (ABS RELAY BOX CIRCUIT - MOTOR PUMP RELAY, SHORT B+)

The motor pump relay supplies battery voltage to the motor pump.

The ABSCM switches the motor relay ON and operates the ABS motor pump.


If a problem occurs in the ABS system, the ABSCM disables the motor pump relay.



59JA0600


| DTC Code | DISPLAY ON SCAN TOOL            | Symptom                                   | Possible Cause   |
|----------|---------------------------------|---|--|
| 35       | MOTOR PUMP                      | Motor pump does not operate               | <ul style="list-style-type: none"> <li>• Motor pump</li> <li>• Motor pump relay</li> <li>• Harness between the ABS and relay box</li> <li>• Harness between power supply and relay box</li> </ul>                    |
| 37       | MOTOR PUMP RELAY - SHORT BATT   | Motor pump relay circuit short to battery | <ul style="list-style-type: none"> <li>• Motor pump relay</li> <li>• ABSCM</li> <li>• Harness between the Relay Box and the ABSCM</li> </ul>   |
| 38       | MOTOR PUMP CIRCUIT - SHORT BATT | Motor pump short to 12V or circuit open   | <ul style="list-style-type: none"> <li>• Motor pump relay</li> <li>• Harness between the ABS modulator and the Relay Box.</li> <li>• Harness between the power supply and Relay Box</li> <li>• Motor pump</li> </ul> |

# WIRING DIAGRAM




## INSPECTION PROCEDURE

Check for voltage between the Relay Box terminal E06-1 and BODY GND. Check motor pump.




### Check ABS-Relay Box (Motor pump relay)





M62 Relay Box connector



M62 Relay Box connector

1. Turn ignition switch to "LOCK" position.
2. Disconnect the Relay Box connector
3. Check for continuity between the terminals as follows.

|                          |               |
|--------------------------|---------------|
| Terminal 3 and 8         | Continuity    |
| Terminal M62-4 and E58-2 | No continuity |

4. Apply battery voltage between terminals 3 and 8.
5. Check for continuity between terminals M62-4 and E58-2.

LIMIT


 Continuity

**OK →** 4

**NG →** 3

Check resistance between each terminal of ABSCM connector


**M60 ABSM harness**  
side connector



1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABSM connector.
3. Check for resistance between terminals 19 and 43.

**LIMIT** 50-60  $\Omega$


**M60 ABSM harness**  
side connector



4. Turn ignition switch to "ON" position.
5. Measure the continuity between terminals as follows.

**LIMIT** Terminals 42 and 27 : 0 V

**M60 ABSM harness**  
side connector



6. Turn ignition switch "LOCK" position.
7. Ground terminal 19 and 28.
8. Turn ignition switch "ON" position.

**LIMIT** Motor running


**NOTE**

Do not apply power for more than 2 seconds.

**OK** → Reconnect the ABSM and recheck from step 1.

**NG** → Repair the Harness


Check Motor pump relay



1. Turn ignition switch to "LOCK" position.
2. Remove the Relay cover.
3. Remove the **Motor** pump relay.
4. Check for continuity terminals between as follows\_

**LIMIT**

|                   |               |
|-------------------|---------------|
| Terminals 1 and 4 | Continuity    |
| Terminals 2 and 3 | No continuity |



5. Apply battery voltage between terminals 1 and 4.
6. Check for continuity between terminals 2 and 3.

**LIMIT** Continuity

**OK-+** Reconnect motor pump relay

**NG-t,** Replace the Motor pump relay


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

CIRCUIT INSPECTION (ABS RELAY BOX CIRCUIT - MOTOR PUMP RELAY, SHORT GND)

Motor pump relay supplies battery voltage to the motor pump. The ABSCM switches the motor relay ON and operates the ABS motor pump.


If a problem occurs in the ABS system, the ABSCM disables the motor pump relay.



59JA0600


| DTC Code | DISPLAY ON SCAN TOOL           | Symptom  | Possible cause  |
|----------|--------------------------------|--|---|
| 36       | MOTOR PUMP RELAY - SHORT GND   | Motor pump relay circuit open or short to ground | <ul style="list-style-type: none"> <li>• Motor pump relay</li> <li>• ABSCM</li> <li>• Harness between the Relay Box and the ABSCM</li> <li>• Harness between the power supply and the relay box</li> </ul>      |
| 39       | MOTOR PUMP CIRCUIT - SHORT GND | Motor pump short to ground                       | <ul style="list-style-type: none"> <li>• Motor pump relay</li> <li>• Harness between the ABS modulator and Relay Box</li> <li>• Harness between the power supply and Relay Box</li> <li>• Motor pump</li> </ul> |

WIRING DIAGRAM



## INSPECTION PROCEDURE

Check for voltage between the Relay Box terminal E58 and BODY GND.



E58 Motor pump harness side connector

1. Turn ignition switch to "LOCK" position.
2. Disconnect the Relay Box connector.
3. Measure for voltage between terminals 2 and body ground.


**LIMIT** 9.0-14.2V

**OK** → 2

**NG** → Repair the Motor harness


V5BR056A

**2. Check the Motor pump relay (Motor pump relay).**



E58 Relay Box harness side connector

M62 Relay Box connector



E58 Relay Box harness side connector

M62 Relay Box connector

1. Turn ignition switch to "LOCK" position.
2. Disconnect the Relay Box connector
3. Check for continuity between the terminals as follows.

|                          |               |
|--------------------------|---------------|
| Terminal 3 and 8         | Continuity    |
| Terminal M62-4 and E58-2 | No continuity |

4. Apply battery voltage between terminals 3 and 8.
5. Check for continuity between terminals M62-4 and E58-2.

**LIMIT** Continuity

**OK** → 4

**NG** → 3

Check the Motor pump relay (Motor pump relay).

**M62** Relay Box connector

**E58** Relay Box harness side connector

**M62** Relay Box connector

**E58** Relay Box harness side connector

1. Turn ignition switch to "LOCK" position.
2. Disconnect the Relay Box connector
3. Check for continuity between the terminals as follows.

|                          |               |
|--------------------------|---------------|
| Terminal 3 and 8         | Continuity    |
| Terminal M62-4 and E58-2 | No continuity |

4. Apply battery voltage between terminals 3 and 8.
5. Check for continuity between terminals M62-4 and E58-2.


LIMIT

 Continuity

**OK** → 4

**NG** → 3


Check the Motor pump relay.



1. Turn ignition switch to "LOCK" position.
2. Remove the Relay-box cover.
3. Remove the Motor pump relay.
4. Check for continuity terminals between as follows.

**LIMIT**

|                   |               |
|-------------------|---------------|
| Terminals 1 and 4 | Continuity    |
| Terminals 2 and 3 | No continuity |



5. Apply battery voltage between terminals 1 and 4.
6. Check for continuity between terminals 2 and 3

**LIMIT**

Continuity


**OK →** Reconnect motor relay

**NG →** Replace the Motor pump relay


Check for resistance between each terminal of the ABSCM connector



M60 ABSCM hame-ss  
side connector



MGO ABSC M harness  
side connector



M60 ABSCM -harness  
side connector



1. Turn ignition switch to "LOCK" position.
2. Disconnect the **ABSCM** connector.
3. **Check** for resistance between terminals 19 and 43.

**LIMIT 1** 50-60  $\Omega$

4. Turn ignition switch to "ON" position.
5. Measure the continuity between terminals as follows.

**LIMIT** Terminals 42 and 27: 0 V

6. Turn ignition switch "LOCK" position.
7. Ground terminal 19 and 28.
8. Turn ignition switch "ON" position.

**LIMIT 1** Mo1m running

#### NOTE

Do not apply power for *more* than 2 seconds.

**QK**

Reconnect the ABSCM and recheck from step 1.

**NG-+** Repair the Harness


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

**CIRCUIT INSPECTION (ABS MODULATOR CIRCUIT - SHORT B+)**


The modulator consists of four solenoid valves, one expander chamber per brake circuit, and a hydraulic pump.

The ABSCM activates the solenoid valves and controls the pressure to the wheel calipers.



| DTC Code | DISPLAY ON SCAN TOOL             | Symptom                                | Possible cause   |
|----------|----------------------------------|--|--|
| 21       | LF SOLENOID CIRCUIT - SHORT BATT | LF solenoid valve short circuit to 12V | <ul style="list-style-type: none"> <li>• ABS Modulator</li> <li>• ABS Relay-BOX</li> <li>• Harness or connector between ABSCM and modulator</li> </ul> |
| 23       | RF SOLENOID CIRCUIT - SHORT BATT | RF solenoid valve short circuit to 12V |  |
| 25       | LR SOLENOID CIRCUIT - SHORT BATT | LR solenoid valve short circuit to 12V |  |
| 27       | RR SOLENOID CIRCUIT - SHORT BATT | RR solenoid valve short circuit to 12V |  |

**WIRING DIAGRAM**



## INSPECTION PROCEDURE

Check for voltage between each terminal of the ABS modulator harness

**M63 Modulator harness side connector**


1. Disconnect the battery negative (-) terminal.
2. Disconnect the ABS modulator connector and ABS/CM connector.
3. Connect the battery negative terminal and ignition ON.
4. Measure the voltage between terminals and body ground as follows:

| LIMIT   |                       |    |
|---------|-----------------------|----|
| SOL. RR | Terminal 5 and ground | 0V |
| SOL. LR | Terminal 6 and ground | 0V |
| SOL. RF | Terminal 7 and ground | 0V |
| SOL. LF | Terminal 8 and ground | 0V |

**OK** → **2**

**NG** → Check and repair harness between terminal 5, 6, 7, 8 and relay box ground.

Check the ABS-Modulator



M63 Modulator connector

1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABS modulator connector.
3. Check the resistance between terminals as follows.


**LIMIT**

|         |                  |             |
|---------|------------------|-------------|
| SOL. RR | Terminal 1 and 5 | 3.10-3.34 Ω |
| SOL. LR | Terminal 2 and 6 | 3.10-3.34 Ω |
| SOL. RF | Terminal 3 and 7 | 3.10-3.34 Ω |
| SOL. LF | Terminal 4 and 8 | 3.10-3.34 Ω |

**OK →** 3

**NG →** Replace the ABS modulator.

Check the ABSCM harness



M60 Modulator harness side connector

1. Disconnect the battery negative (-) terminal.
2. Disconnect ABSCM connector.
3. Connect the battery negative (-) terminal.
4. Turn ignition switch to "ON" position.
5. Measure the voltage between terminals and ground as follows.

|         |                    |     |
|---------|--------------------|-----|
| SOL. RR | Terminal 25 and 27 | 0 V |
| SOL. LF | Terminal 54 and 27 | 0 V |
| SOL. LR | Terminal 53 and 27 | 0 V |
| SOL. RF | Terminal 52 and 27 | 0 V |

**OK →** Reconnect the ABSCM and recheck from step 1.

**NG →** Repair the harness


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## CIRCUIT INSPECTION (ABS MODULATOR CIRCUIT)


The modulator consists of four solenoid valves, one expander chamber per brake circuit, and a hydraulic pump.

The ABSCM activates the solenoid valves and controls the pressure to the wheel calipers.




| DTC Code | DISPLAY ON SCAN TOOL            | Symptom   | Possible cause   |
|----------|---------------------------------|---|--|
| 22       | LF SOLENOID CIRCUIT - SHORT GND | LF solenoid valve open or short-circuit to ground | <ul style="list-style-type: none"> <li>• ABS Modulator</li> <li>• ABS Relay-Box</li> <li>• Harness or connector between the ABSCM and modulator</li> </ul> |
| 24       | RF SOLENOID CIRCUIT - SHORT GND | RF solenoid valve open or short-circuit to ground |  |
| 26       | LR SOLENOID CIRCUIT - SHORT GND | LR solenoid valve open or short-circuit to ground |  |
| 28       | RR SOLENOID CIRCUIT - SHORT GND | RR solenoid valve open or short-circuit to ground |  |

## WIRING DIAGRAM




## INSPECTION PROCEDURE

Check for continuity between each terminal of the ABS modulator harness.



**M60 Modulator harness  
side connector**



1. Disconnect the battery negative (-) terminal.
2. Disconnect the ABS modulator connector and ABSCM connector.
3. Check for continuity between the terminals and body ground as follows.

**LIMIT**

|         |                       |            |
|---------|-----------------------|------------|
| SOL. RR | Terminal 5 and ground | Continuity |
| SOL. RL | Terminal 6 and ground | Continuity |
| SOL. FR | Terminal 7 and ground | Continuity |
| SOL. FL | Terminal 8 and ground | Continuity |

4. Disconnect the ABSCM connector.
5. Ground ABSCM connector terminal 28.
6. Connect the battery negative terminal.
7. Turn ignition switch to "ON" position.
8. Measure voltage between terminals and body ground as follows.

**LIMIT**


|         |                       |            |
|---------|-----------------------|------------|
| SOL. RR | Terminal 5 and ground | 9.0-14.2 V |
| SOL. RL | Terminal 6 and ground | 9.0-14.2 V |
| SOL. FR | Terminal 7 and ground | 9.0-14.2 V |
| SOL. FL | Terminal 8 and ground | 9.0-14.2 V |

**OK → 2**

**NG →** Check and repair the harness between terminal 5, 6, 7, 8 and relay box ground.

SOL. : SOLENOID

Check ABS-Modulator.



M63 Modulator connector

1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABS modulator connector.
3. Check the resistance between terminals as follows.


**LIMIT**

|         |                  |                    |
|---------|------------------|--------------------|
| SOL. RR | Terminal 1 and 5 | 3.10-3.34 $\Omega$ |
| SOL. LR | Terminal 2 and 6 | 3.10-3.34 $\Omega$ |
| SOL. RF | Terminal 3 and 7 | 3.10-3.34 $\Omega$ |
| SOL. LF | Terminal 4 and 8 | 3.10-3.34 $\Omega$ |

**OK** → 3

**NG** → Replace the ABS modulator.

Check ABS/CM harness.



M60 Modulator harness side connector

1. Disconnect the battery negative (-) terminal.
2. Disconnect ABS/CM connector.
3. Connect the battery negative (-) terminal.
4. Turn ignition switch to "ON" position.
5. Measure the voltage between terminals and ground as follows.

|         |                    |     |
|---------|--------------------|-----|
| SOL. RR | Terminal 25 and 27 | 0 V |
| SOL. LF | Terminal 54 and 27 | 0 V |
| SOL. LR | Terminal 53 and 27 | 0 V |
| SOL. RF | Terminal 52 and 27 | 0 V |

**OK** → Reconnect the ABS/CM and recheck from step 1.

**NG** → Repair the harness



|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |


Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

CIRCUIT INSPECTION (SPEED SENSOR CIRCUIT - SHORT TO B+)

At each wheel hub there is a tone wheel and an inductive sensor, which supplies wheel speed information to the ABSCM. The sensor is comprised of a magnet and a pole piece surrounded by a coil. When the tone wheel rotates adjacent to the sensor pole piece, an alternating current signal is generated in the coil with a frequency proportional to wheel speed.


A special integrated circuit in the ABSCM translates the generated AC signal to a square wave.

This square wave is used by the microprocessor to operate the ABS.



| DTC Code | DISPLAY ON SCAN TOOL           | Symptom                                | Possible cause   |
|----------|--------------------------------|--|--|
| 62       | LF WHEEL SENSOR - CIRCUIT OPEN | Sensor LF circuit open or short to 12V | <ul style="list-style-type: none"> <li>Wheel speed sensor</li> <li>Harness or connector between the wheel speed sensor and ABSCM</li> <li>ABSCM</li> </ul> |
| 63       | RF WHEEL SENSOR - CIRCUIT OPEN | Sensor RF circuit open or short to 12V |  |
| 64       | LR WHEEL SENSOR - CIRCUIT OPEN | Sensor LR circuit open or short to 12V |  |
| 65       | RR WHEEL SENSOR - CIRCUIT OPEN | Sensor RR circuit open or short to 12V |  |

WIRING DIAGRAM




## INSPECTION PROCEDURE

Check Wheel Speed Sensor.

|                             |  |   |
|-----------------------------|--|---|
|                             | <p>E56 LF WHEEL SENSOR<br/>M66 FR WHEEL SENSOR<br/>M01 LR WHEEL SENSOR<br/>M67 RR WHEEL SENSOR</p> | <ol style="list-style-type: none"> <li>1. Disconnect the wheel speed sensor.</li> <li>2. Measure the resistance between terminals 1 and 2 the of wheel speed sensor connector.</li> </ol> |
|                             | <p>E56 LF WHEEL SENSOR<br/>M66 FR WHEEL SENSOR<br/>M01 LR WHEEL SENSOR<br/>M67 RR WHEEL SENSOR</p> | <ol style="list-style-type: none"> <li>3. Measure voltage between wheel speed sensor connector terminals 1, 2 and body ground.</li> </ol>   |
| <p><b>OK</b> → <b>2</b></p> | <p><b>NG</b> → Replace wheel speed sensor</p>  |   |

Check the harness and connector between the ABSCM and each wheel speed sensor



1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABS sensor connector.
3. Turn ignition switch to "ON" position.
4. Measure the resistance between the terminals as follows.

#### LIMIT

|         |                     |                     |
|---------|---------------------|---------------------|
| SNSR.LF | Terminals 33 and 34 | 1275-1495 $\Omega$  |
| SNSA.AF | Terminals 1 and 31  | 12, s-1495 $\Omega$ |
| SNSR.LR | Terminals 29 and 3  | 1260-1540 $\Omega$  |
| SNSR.RA | Terminals 36 and 37 | 1250-1540 $\Omega$  |

5. Measure the voltage between sensor terminals and body ground terminals as follows.

#### LIMIT

|         |                     |    |
|---------|---------------------|----|
| SNSR.FL | Terminals 34 and 27 | 0V |
| SNSA.FR | Terminals 1 and 27  | 0V |
| SNSR.RL | Terminals 29 and 27 | 0V |
| SNSR.RR | Terminals 36 and 27 | 0V |

SNSR: SENSOR

|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |


Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

**CIRCUIT INSPECTION (SPEED SENSOR CIRCUIT - SHORT GND)**

At each wheel hub there is a tone wheel and an inductive sensor, which supplies the wheel speed information to the ABSCM. The sensor is comprised of a magnet and a pole piece surrounded by a coil. When the tone wheel rotates adjacent to the sensor pole piece, an alternating current signal is generated in the coil with a frequency proportional to wheel speed.


A special integrated circuit in the ABSCM translates the generated AC signal to a square wave.

This square wave is used by the microprocessor to operate the ABS.



| DTC Code | DISPLAY ON SCAN TOOL        | Symptom                           | Possible cause   |
|----------|-----------------------------|-----------------------------------|--|
| 66       | LF WHEEL SENSOR - SHORT GND | Sensor LF circuit short to ground | <ul style="list-style-type: none"> <li>• Wheel speed sensor</li> <li>• Harness or connector between the wheel speed sensor and ABSCM</li> <li>• ABSCM</li> </ul> |
| 67       | RF WHEEL SENSOR - SHORT GND | Sensor RF circuit short to ground |  |
| 68       | LR WHEEL SENSOR - SHORT GND | Sensor LR circuit short to ground |  |
| 69       | RR WHEEL SENSOR - SHORT GND | Sensor RR circuit short to ground |  |

**WIRING DIAGRAM**




## INSPECTION PROCEDURE

Check Wheel Speed Sensor

|                             |  |   |
|-----------------------------|--|---|
|                             | <p>E56 LF WHEEL SENSOR<br/>M66 FR WHEEL SENSOR<br/>M01 LR WHEEL SENSOR<br/>M67 RR WHEEL SENSOR</p> | <p>1. Disconnect the wheel speed sensor.<br/>2. Measure the resistance between terminals 1 and 2 the of wheel speed sensor connector.</p> <p><b>LIMIT</b> 1000-1200 Ω</p> |
|                             | <p>E56 LF WHEEL SENSOR<br/>M66 FR WHEEL SENSOR<br/>M01 LR WHEEL SENSOR<br/>M67 RR WHEEL SENSOR</p> | <p>3. Measure voltage between wheel speed sensor connector terminals 1, 2 and body ground.</p> <p><b>LIMIT</b> 0 V</p>  |
| <p><b>OK</b> → <b>2</b></p> |  | <p><b>NG</b> → Replace wheel speed sensor</p>   |

Check the harness and the connector between the ABSCM and each wheel speed sensor



1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABSCM connector.
3. Turn ignition switch to "ON" position.
4. Measure the resistance between the terminals as follows.

**LIMIT**

|         |                     |             |
|---------|---------------------|-------------|
| SNSR.LF | Terminals 33 and 34 | 1275-1495 Ω |
| SNSR.FR | Terminals 1 and 31  | 1275-1495 Ω |
| SNSR.LR | Terminals 29 and 3  | 1260-1540 Ω |
| SNSR.RR | Terminals 36 and 37 | 1260-1540 Ω |

5. Measure the voltage between sensor terminals and body ground terminals as follows.

**LIMIT**

|         |                     |     |
|---------|---------------------|-----|
| SNSR.FL | Terminals 34 and 27 | 0 V |
| SNSR.FR | Terminals 1 and 27  | 0 V |
| SNSR.RL | Terminals 29 and 27 | 0 V |
| SNSR.RR | Terminals 36 and 27 | 0 V |

**OK →** Re-connect the ABSCM and re-check

**NG →** Repair the harness

SNSR. : SENSOR  
SNSR.: SENSOR

|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |


Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

CIRCUIT INSPECTION (SPEED SENSOR CIRCUIT - AIR GAP SYMPTOM)

At each wheel hub there is a tone wheel and an inductive sensor, which supplies the wheel speed information to the ABSCM. The sensor is comprised of a magnet and a pole piece surrounded by a coil. When the tone wheel rotates adjacent to the sensor pole piece, an alternating current signal is generated in the coil with a frequency proportional to wheel speed.


A special integrated circuit in the ABSCM translates the generated AC signal to a square wave.

This square wave is used by the microprocessor to operate the ABS.



| DTC Code | DISPLAY ON SCAN TOOL          | Symptom                        | Possible cause   |
|----------|-------------------------------|--------------------------------|--|
| 31       | LF WHEEL SPEED SENSOR AIR GAP | Air gap ON sensor LF incorrect | <ul style="list-style-type: none"> <li>Wheel speed sensor air gap</li> <li>Wheel speed sensor</li> <li>Harness or connector between the wheel speed sensor and ABSCM</li> <li>ABSCM</li> </ul> |
| 32       | RF WHEEL SPEED SENSOR AIR GAP | Air gap ON sensor RF incorrect |  |
| 33       | LR WHEEL SPEED SENSOR AIR GAP | Air gap ON sensor LR incorrect |  |
| 34       | RR WHEEL SPEED SENSOR AIR GAP | Air gap ON sensor RR incorrect |  |

WIRING DIAGRAM




## INSPECTION PROCEDURE

Check Wheel Speed Sensor

|                             |  |   |
|-----------------------------|--|---|
|                             | <p>E56 LF WHEEL SENSOR<br/>M66 FR WHEEL SENSOR<br/>M01 LR WHEEL SENSOR<br/>M67 RR WHEEL SENSOR</p> | <ol style="list-style-type: none"> <li>1. Disconnect the wheel speed sensor.</li> <li>2. Measure the resistance between terminals 1 and 2 the of wheel speed sensor connector.</li> </ol> |
|                             | <p>E56 LF WHEEL SENSOR<br/>M66 FR WHEEL SENSOR<br/>M01 LR WHEEL SENSOR<br/>M67 RR WHEEL SENSOR</p> | <ol style="list-style-type: none"> <li>3. Measure voltage between wheel speed sensor connector terminals 1, 2 and body ground.</li> </ol>   |
| <p><b>OK</b> → <b>2</b></p> | <p><b>NG</b> → Replace wheel speed sensor</p>  |   |

Check the harness and the connector between the ABSCM and each wheel speed sensor





1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABSCM connector.
3. Turn ignition switch to "ON" position.
4. Measure the resistance between the terminals as follows.

#### LIMIT

|         |                     |                     |
|---------|---------------------|---------------------|
| SNSR.LF | Terminals 33 and 34 | 1275-1495 $\Omega$  |
| SNSA.AF | Terminals 1 and 31  | 12, s-1495 $\Omega$ |
| SNSR.LR | Terminals 29 and 3  | 1260-1540 $\Omega$  |
| SNSR.RA | Terminals 36 and 37 | 1250-1540 $\Omega$  |

5. Measure the voltage between sensor terminals and body ground terminals as follows.

#### LIMIT

|         |                     |    |
|---------|---------------------|----|
| SNSR.FL | Terminals 34 and 27 | 0V |
| SNSA.FR | Terminals 1 and 27  | 0V |
| SNSR.RL | Terminals 29 and 27 | 0V |
| SNSR.RR | Terminals 36 and 27 | 0V |

SNSR: SENSOR

|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |


Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## CIRCUIT INSPECTION (SPEED SENSOR CIRCUIT - SPEED JUMP SYMPTOM)

At each wheel hub there is a tone wheel and an inductive sensor, which supplies the wheel speed information to the ABSCM. The sensor is comprised of a magnet and a pole piece surrounded by a coil. When the tone wheel rotates adjacent to the sensor pole piece, an alternating current signal is generated in the coil with a frequency proportional to wheel speed.


A special integrated circuit in the ABSCM translates the generated AC signal to a square wave.

This square wave is used by the microprocessor to operate the ABS.





| DTC Code | DISPLAY ON SCAN TOOL        | Symptom                            | Possible cause   |
|----------|-----------------------------|------------------------------------|--|
| 71       | LF TONE WHEEL TOOTH MISSING | Speed jump on the exciter wheel FL | <ul style="list-style-type: none"> <li>• Tone wheel</li> <li>• Wheel speed sensor</li> <li>• Harness or connector between the wheel speed sensor and the ABSCM</li> <li>• ABSCM</li> </ul> |
| 72       | RF TONE WHEEL TOOTH MISSING | Speed jump on the exciter wheel FR |  |
| 73       | LR TONE WHEEL TOOTH MISSING | Speed jump on the exciter wheel RL |  |
| 74       | RR TONE WHEEL TOOTH MISSING | Speed jump on the exciter wheel RR |  |
| 19       | DEFECTIVE TONE WHEEL        | Check the tone wheels              | <ul style="list-style-type: none"> <li>• Tone wheel</li> <li>• Wheel speed sensor and harness</li> </ul>   |

WIRING DIAGRAM




INSPECTION PROCEDURE

Check Wheel Speed Sensor

|  |  |
|--|--|
|  <p><b>E56 LF WHEEL SENSOR</b><br/><b>M66 FR WHEEL SENSOR</b><br/><b>M01 LR WHEEL SENSOR</b><br/><b>M67 RR WHEEL SENSOR</b></p> | <ol style="list-style-type: none"><li>1. Disconnect the wheel speed sensor.</li><li>2. Measure the resistance between terminals 1 and 2 the of wheel speed sensor connector.</li></ol> <p><b>LIMIT</b> 1000-1200 Ω</p> |
|  <p><b>E56 LF WHEEL SENSOR</b><br/><b>M66 FR WHEEL SENSOR</b><br/><b>M01 LR WHEEL SENSOR</b><br/><b>M67 RR WHEEL SENSOR</b></p> | <ol style="list-style-type: none"><li>3. Measure voltage between wheel speed sensor connector terminals 1, 2 and body ground.</li></ol> <p><b>LIMIT</b> 0 V</p>  |
| <b>OK →</b> <b>2</b>   | <b>NG →</b> Replace wheel speed sensor   |

Check the harness and the connector between the ABSCM and each wheel speed sensor



1. Turn ignition switch to "LOCK" position.
2. Disconnect the ABSCM connector.
3. Turn ignition switch to "ON" position.
4. Measure the resistance between the terminals as follows.

**LIMIT**

|         |                     |             |
|---------|---------------------|-------------|
| SNSR.LF | Terminals 33 and 34 | 1275-1495 Ω |
| SNSR.FR | Terminals 1 and 31  | 1275-1495 Ω |
| SNSR.LR | Terminals 29 and 3  | 1260-1540 Ω |
| SNSR.RR | Terminals 36 and 37 | 1260-1540 Ω |

5. Measure the voltage between sensor terminals and body ground terminals as follows.

**LIMIT**




|         |                     |     |
|---------|---------------------|-----|
| SNSR.FL | Terminals 34 and 27 | 0 V |
| SNSR.FR | Terminals 1 and 27  | 0 V |
| SNSR.RL | Terminals 29 and 27 | 0 V |
| SNSR.RR | Terminals 36 and 27 | 0 V |

**OK →** Re-connect the ABSCM and re-check

**NG →** Repair the harness

SNSR. : SENSOR

Check tone wheel and sensor installation



### Front

- o **Remove** the front tone **whe**
- o Check the tone wheel teeth *tot* mlssing or scratches.

Limit Tone wh OK

- o Check the tone whee teeth for missing of scratches.

Limit Tone wheel OK

### ALL

- o Check the air gap between the wheel speed sensors and the tone wheel teeth.

Limit FRONT: 0.2- i 3 m m (0.008-0 .051 \_in.)  
REAR : 0.2•1.3 mrn(0.008-0.051 ,n .}

**OK+** Re-connect the ABSCM and re-chedc.

**NG..** Replace the components.


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## STOP LAMP SWITCH CIRCUIT


The stop lamp switch senses whether the brake pedal is depressed or released, and sends the signal to the ABSCM

### WIRING DIAGRAM



### INSPECTION PROCEDURE

Check the stop lamp switch circuit



M60 ABSCM harness  
side connector

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |

1. Remove battery negative(-) terminal.
2. Remove the ABSCM and disconnect the connector.
3. Connect battery negative(-) terminal.
4. Turn ignition switch to ON position.
5. Measure the supply voltage between terminals 15 and 27.

**LIMIT** 9.5V 14.2V

**OK**

Connect the ABSCM and re-check the diagnostic code. If code 6, 57 displayed, check for the ABSCM poor connection.

**NG-+, r"jl**


|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

**DATA-LINK CIRCUIT**

When a fault is detected the ABSCM, a code is stored in the ABSCM memory. The SCAN TOOL can be used to read the codes in the ABSCM memory.

**WIRING DIAGRAM**



**INSPECTION PROCEDURE**

Check for voltage supply of ABSCM.



**M60 ABS/CM harness  
side connector**

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |



1. Remove battery negative(-) terminal.
2. Remove the ABS/CM and disconnect the connector.
3. Connect battery negative(-) terminal.
4. Turn ignition switch to ON position.
5. Measure the supply voltage between terminals 50 and 27.

**LIMIT** 9.5V - 14.2V


**OK→** Connect the ABS/CM and re-check the diagnostic code. If code 56, 57 displayed, check for the ABS/CM poor connection.

**NG→** **3**

Check continuity between the ABS/CM connector GND and Body GND.

**M60 ABS/CM harness  
side connector**

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |



1. Turn the ignition switch to the LOCK position.
2. Disconnect ABS/CM connector.
3. Measure the ground connection between terminal 27 and body ground, terminal 26 and body ground, terminals 51 and body ground.

**LIMIT** 0.5 Ω or below



**OK→** Check for an open between the harness and the connector between the ABS/CM and the battery

- NG→**
1. Check ground connection for corrosion and loosening
  2. Repair harness or connector.

|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## WHEEL SPEED SENSOR




**TORQUE : Nm (kg·cm, lb·ft)**

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## REMOVAL


Disconnect the wheel speed sensor connector and mounting bolts.



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)


## INSPECTION

Connect an ohmmeter between the wheel speed sensor terminals and measure the resistance.



| RESISTANCE SPECIFICATION |                    |
|--------------------------|--------------------|
| Service standard (Front) | 1275-1495 $\Omega$ |
| Service standard (Rear)  | 1260-1540 $\Omega$ |

Connect a voltmeter between the wheel speed sensor terminals, and measure the voltage by turning the wheel.



## NOTE

Set the voltmeter to measure AC voltage.

Service standard: AC voltage detected.


Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## BLEEDING OF BRAKE SYSTEM

### NOTE

There is no special bleeding procedure for the ABS SYSTEM. For bleeding, please use the standard rules as described for the conventional brake system as follows.

Remove the reservoir cap and fill the brake reservoir with brake fluid.




### CAUTION

Do not allow brake fluid to remain on a painted surface. Wash it off immediately.

### NOTE

When bleeding by pressurized fluid, do not depress the brake pedal.

Connect the vinyl tube to the wheel cylinder bleeder screw, and insert the other end of tube in a half-full container of brake fluid.



Slowly pump the brake pedal several times.


While depressing the brake pedal fully, loosen the bleeder screw until fluid starts to run out. Then close the bleeder screw.

Repeat steps 3 and 4 until there are no more bubbles in the fluid.

Tighten the bleeder plug screw.

| TORQUE SPECIFICATION |   |
|----------------------|---|
| Bleed screw (front)  | 7-13 Nm ( 70-130 kg·cm,<br>5-10 lb·ft ) |
| Bleed screw (rear)   | 8-20 Nm ( 80-200 kg·cm,<br>6-15 lb·ft ) |

Repeat the above procedure for each wheel in the sequence shown in the illustration.



# ELECTRICAL TROUBLESHOOTING MANUAL

Applies to: [Hyundai Coupe/Tiburon 1998-1999](#)

## GROUP

Brake Systems

Anti-lock Brake System

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## ANTI-LOCK BRAKING SYSTEM CONTROL MODULE

### ABSCM CONNECTOR (M60, ABSCM HARNESS SIDE CONNECTOR)

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |    |
| 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |

| PIN NO | PLUG ASSIGNMENT            | I/O | PIN NO | PLUG ASSIGNMENT          | I/O |
|--------|----------------------------|-----|--------|--------------------------|-----|
| 1      | SENSOR RIGHT FRONT         | I   | 32     | SENSOR LEFT FRONT        | I   |
| 3      | SENSOR LEFT REAR<br>GROUND | I   | 34     | SENSOR LEFT FRONT<br>GND | I   |
| 13     | MIL FLASH CODE             | O   | 36     | SENSOR RIGHT REAR        | I   |
| 15     | BRAKE LIGHT SWITCH         | I   | 37     | SENSOR RIGHT REAR<br>GND | I   |
| 17     | ABS SRI                    | O   | 42     | MOTOR MONITOR LINE       | I   |
| 19     | MOTOR RELAY DRIVE          | O   | 43     | F/SF RELAY MONITOR       | I   |
| 25     | SOLENOID REAR RIGHT        | O   | 44     | DLC INPUT/OUTPUT         | I/O |
| 26     | GROUND FOR<br>SOLENOIDS    | I   | 50     | IGNITION SIGNAL          | I   |
| 27     | GROUND FOR<br>SOLENOIDS    | I   | 51     | CONTROLLER GROUND        | I   |
| 28     | F/SF RELAY DRIVE           | O   | 52     | SOLENOID RIGHT FRONT     | O   |
| 29     | SENSOR LEFT REAR           | I   | 53     | SOLENOID LEFT REAR       | O   |
| 31     | SENSOR RIGHT FRONT<br>GND  | I   | 54     | SOLENOID LEFT FRONT      | O   |

I: INPUT

MIL: Malfunction Indicator Light

O: OUTPUT

SRI: Service Reminder Indicator


F/SF: Fail safe

DLC: Data Link Connector


Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## REMOVAL

Remove the luggage side trim.




Remove the ABSCM and disconnect connector.



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## ABSCM (ABS CONTROL MODULE)





# ELECTRICAL TROUBLESHOOTING MANUAL

Applies to: [Hyundai Coupe/Tiburon 1998-1999](#)

## GROUP


Brake Systems

Anti-lock Brake System

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## ANTI-LOCK BRAKING SYSTEM MODULATOR

### MODULATOR CONNECTOR (M63, HARNESS SIDE)



| PIN NO. | PLUG ASSIGNMENT          | PIN NO. | PLUG ASSIGNMENT          |
|---------|--------------------------|---------|--------------------------|
| 1       | RIGHT REAR SOLENOID GND  | 5       | RIGHT REAR SOLENOID GND  |
| 2       | LEFT REAR SOLENOID GND   | 6       | LEFT REAR SOLENOID GND   |
| 3       | RIGHT FRONT SOLENOID GND | 7       | RIGHT FRONT SOLENOID GND |
| 4       | LEFT FRONT SOLENOID GND  | 8       | LEFT FRONT SOLENOID GND  |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## RELAY BOX CONNECTOR (M62, HARNESS SIDE)



| PIN NO. | PLUG ASSIGNMENT          | PIN NO. | PLUG ASSIGNMENT          |
|---------|--------------------------|---------|--------------------------|
| 1       | RIGHT REAR SOLENOID GND  | 5       | RIGHT REAR SOLENOID GND  |
| 2       | LEFT REAR SOLENOID GND   | 6       | LEFT REAR SOLENOID GND   |
| 3       | RIGHT FRONT SOLENOID GND | 7       | RIGHT FRONT SOLENOID GND |
| 4       | LEFT FRONT SOLENOID GND  | 8       | LEFT FRONT SOLENOID GND  |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSTALLATION


Follow the reverse order of removal.

Tighten the modulator mounting bolts and brake tube nuts to the specified torque.

| TORQUE SPECIFICATION    |   |
|-------------------------|---|
| Modulator mounting bolt | 17-26 Nm ( 170-260 kg·cm, 12-19 lb·ft ) |
| Brake tube nut          | 13-17 Nm ( 130-170 kg·cm, 9-12 lb·ft )  |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## COMPONENTS




**TORQUE : Nm (kg·cm, lb·ft)**

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)


## REMOVAL

Push up the power steering fluid reservoir.


Disconnect the ABS Relay box harness, Motor Pump harness and modulator harness located in right front fender.



Disconnect the brake tubes from the ABS modulator to the brake master cylinder and proportioning valve.



Remove the Modulator mounting Bracket and remove the modulator.





### **CAUTION**

1. Never attempt to disassemble the ABS modulator.
2. The modulator must be transported and stored in upright position and with sealed ports. The modulator must not be drained.

|   |                        |
|---|------------------------|
| <b>SERVICE MANUAL</b>                                       |                        |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                        |
| <b>GROUP</b>  |                        |
| Brake Systems   | Anti-lock Brake System |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## WHEEL SPEED SENSOR




**TORQUE : Nm (kg·cm, lb·ft)**

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## REMOVAL


Disconnect the wheel speed sensor connector and mounting bolts.



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)


## INSPECTION

Connect an ohmmeter between the wheel speed sensor terminals and measure the resistance.



| RESISTANCE SPECIFICATION |                    |
|--------------------------|--------------------|
| Service standard (Front) | 1275-1495 $\Omega$ |
| Service standard (Rear)  | 1260-1540 $\Omega$ |

Connect a voltmeter between the wheel speed sensor terminals, and measure the voltage by turning the wheel.



## NOTE

Set the voltmeter to measure AC voltage.

Service standard: AC voltage detected.


Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## BLEEDING OF BRAKE SYSTEM

### NOTE

There is no special bleeding procedure for the ABS SYSTEM. For bleeding, please use the standard rules as described for the conventional brake system as follows.

Remove the reservoir cap and fill the brake reservoir with brake fluid.




### CAUTION

Do not allow brake fluid to remain on a painted surface. Wash it off immediately.

### NOTE

When bleeding by pressurized fluid, do not depress the brake pedal.

Connect the vinyl tube to the wheel cylinder bleeder screw, and insert the other end of tube in a half-full container of brake fluid.



Slowly pump the brake pedal several times.


While depressing the brake pedal fully, loosen the bleeder screw until fluid starts to run out. Then close the bleeder screw.

Repeat steps 3 and 4 until there are no more bubbles in the fluid.

Tighten the bleeder plug screw.

| TORQUE SPECIFICATION |   |
|----------------------|---|
| Bleed screw (front)  | 7-13 Nm ( 70-130 kg·cm,<br>5-10 lb·ft ) |
| Bleed screw (rear)   | 8-20 Nm ( 80-200 kg·cm,<br>6-15 lb·ft ) |

Repeat the above procedure for each wheel in the sequence shown in the illustration.




|   |                      |
|---|----------------------|
| <b>SERVICE MANUAL</b>                                       |                      |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                      |
| <b>GROUP</b>  |                      |
| Brake Systems   | Parking Brake System |


Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## REMOVAL

Remove the console upper cover.




Remove the crash pad center facia panel.



Remove the console assembly.






Remove the parking cable adjusting nut.

Detach the parking brake switch assembly.

Remove the parking brake lever assembly.




Remove the wheel and tire.


Remove the brake drum.

Remove the brake shoes as outlined before.


Detach the parking brake cable from the brake shoe.



Remove the parking cable retaining ring in the rear of the backing plate.




Remove the rear seat cushion assembly and roll up the carpet.



Loosen the parking brake cable clamp and remove the parking brake cable assembly.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## COMPONENTS



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSPECTION

Check the parking brake switch operation.


Check the parking brake lever ratchet for wear.

Check the parking brake cable for fraying or damage.


Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSTALLATION


Check the parking brake cables for left and right identification marks and install accordingly.




Move the adjuster lever all the way back when installing the shoe-to-shoe spring.



Install the grommets in the direction shown in the illustration.



Apply a coating of the specified grease to the sliding pads of the ratchet plate and ratchet pawl.



Specified grease: Multipurpose grease SAE J310, NLGI No. 2

After installing the cable adjuster, adjust the parking brake lever stroke.


|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## ADJUSTMENT


Clearance between the stop lamp switch outer case and pedal arm.

| MEASUREMENT SPECIFICATION |                                   |
|---------------------------|-----------------------------------|
| "A"                       | 0.5 - 1.0 mm ( 10.02 - 0.039 in ) |




Free play of brake pedal B

| MEASUREMENT SPECIFICATION  |                           |
|----------------------------|---------------------------|
| Free play of brake pedal C | 3-8 mm ( 0.118-0.315 in ) |



Start the engine, apply the brake pedal with approximately 500 N (50 kg, 110 lbs.) of force, and measure pedal stroke.




**Standard value:** Pedal stroke "C" When pedal is depressed 50 kg (110 lb.) force 145 mm(1.776 in.) or more

|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## BLEEDING OF BRAKE SYSTEM

Remove the reservoir cap and fill the brake reservoir with brake fluid.




### CAUTION

Do not allow brake fluid on a painted surface. Wash it off immediately.

### NOTE

When bleeding by pressurized fluid, do not depress the brake pedal.

Connect the vinyl tube to the wheel cylinder bleeder plug, and insert the other end of tube in a half-full container of brake fluid.



Slowly pump the brake pedal several times.


While depressing the brake pedal fully, loosen the bleeder plug until fluid starts to run out. Then close the bleeder screw,

Repeat steps 3 and 4 until there are no more bubbles in the fluid.

Tighten the bleeder plug screw.

| TORQUE SPECIFICATION |  |
|----------------------|--|
| Bleeder screw        | 7-9 Nm ( 70-90 kg·cm,<br>5.1-6.6 lb·ft ) |

Repeat the above procedure for each wheel in the sequence shown in the illustration.






|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)


## BRAKE PEDAL COMPONENTS



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## DISASSEMBLY

Remove the stop lamp switch.




Remove the flange nuts (4EA) & bolt (1EA) of the brake mounting bracket.

Remove the clevis pin.

Remove the brake pedal assembly.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSPECTION



**BRAKE SWITCH CHECK**

Check the bushing for wear.

Check the brake pedal for distortion.

Check the brake pedal return spring for damage.


Check the stop lamp switch.

With an ohmmeter connected to the stop lamp switch terminals, check for continuity.

If there is no continuity when the plunger is depressed and there is continuity when the plunger is released, the stop lamp switch is normal

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSTALLATION



Apply chassis grease to the sliding surface of the brake pedal and operating rod clevis pin.

### CAUTION

**Be sure to install the split pin on the operating rod clevis pin.**

Install the brake pedal assembly and tighten the flange nuts (booster mounting nuts) and bolt.

#### TORQUE SPECIFICATION

|                         |                                      |
|-------------------------|--------------------------------------|
| Tighten the flange nuts | 8-12 Nm ( 80-120 kg·cm,<br>? lb·ft ) |
|-------------------------|--------------------------------------|

Adjust the brake pedal height and free play.

Install the stop lamp switch.


|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)


## BRAKE BOOSTER OPERATION TEST WITHOUT A TESTER

For a simple check of brake booster operation, make the following tests.

Run the engine for one or two minutes, and then stop it. Depress the brake pedal several times at normal foot pressure. If the pedal goes down further at the first time, but gradually rises after the second or third time, the brake booster is functioning properly. Go to step 2.



With the engine stopped, depress the brake pedal several times. Depress the brake pedal and start the engine. If the pedal goes down slightly, the booster is in good condition. Go to step 3.




With the engine running, depress the brake pedal and then stop the engine. Hold the pedal depressed for 30 seconds. If the pedal height does not change, the booster is in good condition.

If one of the above three tests is not okay, check the vacuum hoses and the brake booster, make any necessary corrections. If all tests are OK, the unit is good

|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s):
 [Mechanical Manual](#)
[Electrical Manual](#)

COMPONENTS



**TORQUE : Nm (kg·cm, lb·ft)**

Return to Main Menu(s):
 [Mechanical Manual](#)
[Electrical Manual](#)


CHECK VALVE OPERATING TEST

Remove the booster hose from the check valve.

Start the engine.


Plug the check valve hole with a finger.

Check on the basis of finger touch that vacuum is present.



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## REMOVAL




Disconnect the brake tube from the master cylinder.

Remove the master cylinder.

### CAUTION

**Do not allow brake fluid to remain on a painted surface. Wash it off immediately.**

Disconnect the vacuum hose the booster.



Remove the operating rod from the brake pedal.

Remove the stop lamp switch.


Loosen the booster mounting nuts.

Lift out the booster assembly.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSTALLATION


When the booster assembly is installed, replace the packing at each end of the booster mounting holder, if necessary.



Install brake booster and tighten the mounting nuts.

| TORQUE SPECIFICATION |  |
|----------------------|--|
| Mounting nuts        | 8-12 Nm ( 80-120 kg·cm,<br>6-9 lb·ft ) |

Connect clevis to brake pedal with clevis pin and install the split pin to the clevis pin.



Install master cylinder and connect the brake tube to the master cylinder.

Connect vacuum hose to brake booster.

Pay attention to the direction of the check valve when installing.

Fill brake reservoir with brake fluid and bleed the system.

Check for fluid leakage.

Check and adjust the brake pedal.

After installation, apply sufficient grease to the clevis and brake pedal contacting points.



|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## REASSEMBLY

Install the brake hoses without twisting them.

The brake tubes should be installed away from sharp edges, weld beads or moving parts.

Tighten the connections to the specified torque.

| TORQUE SPECIFICATION        |   |
|-----------------------------|---|
| Flare nuts                  | 13-17 Nm ( 130-170 kg·cm, 9-12 lb·ft )  |
| Brake hose to front caliper | 25-30 Nm ( 250-300 kg·cm, 18-22 lb·ft ) |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## INSPECTION

Check the brake lines for cracks, crimps and corrosion.


Check the brake hoses for cracks, damage and leakage.

Check the brake line flare nuts for damage and leakage.


Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## COMPONENTS

[ABS]



{Non ABS}




TORQUE: Nm (kg-cm, lb•ft)

|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)


## BRAKE PEDAL COMPONENTS



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## DISASSEMBLY

Remove the stop lamp switch.




Remove the flange nuts (4EA) & bolt (1EA) of the brake mounting bracket.

Remove the clevis pin.

Remove the brake pedal assembly.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSPECTION



**BRAKE SWITCH CHECK**

Check the bushing for wear.

Check the brake pedal for distortion.

Check the brake pedal return spring for damage.


Check the stop lamp switch.

With an ohmmeter connected to the stop lamp switch terminals, check for continuity.

If there is no continuity when the plunger is depressed and there is continuity when the plunger is released, the stop lamp switch is normal

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSTALLATION



Apply chassis grease to the sliding surface of the brake pedal and operating rod clevis pin.

### CAUTION

**Be sure to install the split pin on the operating rod clevis pin.**

Install the brake pedal assembly and tighten the flange nuts (booster mounting nuts) and bolt.

#### TORQUE SPECIFICATION

|                         |                                      |
|-------------------------|--------------------------------------|
| Tighten the flange nuts | 8-12 Nm ( 80-120 kg·cm,<br>? lb·ft ) |
|-------------------------|--------------------------------------|


Adjust the brake pedal height and free play.

Install the stop lamp switch.

|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s):
     [Mechanical Manual](#)
     [Electrical Manual](#)

COMPONENTS




**TORQUE : Nm {kg-cm, lb-ft}**

Return to Main Menu(s):
     [Mechanical Manual](#)
     [Electrical Manual](#)

REPLACEMENT OF BRAKE PADS


The brake pads have wear indicators that contact the brake disc when the brake pad thickness becomes 2 mm (0.08 in.) or less. The wear indicators will generate a squealing sound to warn the driver.



## REMOVAL

Remove the lower bolt and lift the caliper assembly up and out of the way. Secure it with wire or some other retaining method.

Remove the pads.



### CAUTION

Do not depress the brake pedal while disassembling the pads.

## INSPECTION

Check the pads for wear or oil contamination and replace, if necessary.

### NOTE

The pads for the right and left wheels should be replaced at the same time. Never "split" or intermix brake pad sets. All four pads must be replaced as a complete set.


|                           | Standard value | Service limit |
|---------------------------|----------------|---------------|
| Pad thickness<br>mm (in.) | 11 (0.433)     | 2.0 (0.079)   |

Check the shims for damage or deformation


Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## BEARING REPLACEMENT

Remove the snap ring.



Install the special tools as illustrated.




Secure the knuckle in a vise.

Tighten the nut of the special tool and remove the front hub from the knuckle.

### NOTE

**When removing wheel hub or wheel bearing from knuckle, replace wheel bearing assembly (outer race, inner races and grease seals) with a new one.**

Remove the wheel bearing inner race (outside) from the front hub by using the special tool.






**NOTE**

**When removing the inner race (outside) from the hub, be careful not to drop the hub.**


Install the inner race (outside) that was removed from the hub to the wheel bearing, and then use the special tool to remove the wheel bearing.



Fill the wheel bearing with multipurpose grease.


Apply a thin coating of multipurpose grease to the knuckle and bearing contact surfaces.

Press-in the bearing by using the special tool.

**NOTE**

**Do not press inner race of wheel bearing assembly.**

Install snap ring into groove of knuckle.



Install the disc to the hub and torque to specification.


| TORQUE SPECIFICATION |   |
|----------------------|---|
| Torque               | 50-60 Nm ( 500-600 kg·cm, 36-43 lb·ft ) |

Use the special tool to mount the hub onto the knuckle.

Tighten the hub to the knuckle to 200-260 Nm (2000-2600 kg.cm, 148-192 lb.ft) with the special tool.

Rotate the hub to seat the bearing.

Measure the hub bearing starting torque.



| MEASUREMENT SPECIFICATION   |                                      |
|-----------------------------|--------------------------------------|
| Hub bearing starting torque | 1.3 mm ( 13 kg.cm,lb.in or less in ) |

If the starting torque is 0 Nm (0 lb-in), measure the hub bearing axial play.

If the hub axial play exceeds the limit while the nut is tightened to 200-260 Nm (2,000-2,600 kg.cm, 148-192 lb.ft), the bearing, hub and knuckle have not been installed correctly. Repeat the disassembly and assembly procedure.

| MEASUREMENT SPECIFICATION |                        |
|---------------------------|------------------------|
| Hub bearing axial play    | 0.008 mm ( 0.0003 in ) |


Remove the special tool.

|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2000</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## CALIPER ASSEMBLY

### REMOVAL



Remove the wheel and tire.


Disconnect the brake hose.

Remove the pads.

Remove the sleeve.

Remove the pin boot and sleeve boot.

Remove the caliper assembly.



Check the caliper for wear, damage, cracks and rust.

Check the piston for rust, damage, cracks and wear on the outer surface.

Check the sleeve and pin for damage and rust.

Check the pad spring and boots for damage.

Check the carrier for damage, rust, wear and cracks.


**NOTE**

1. Do not use sand paper on the piston surface.
1. All rubber parts must be replaced with new ones.

Inspect the disc using a caliper and dial gauge.

|  | Standard value | Service limit |
|--|----------------|---------------|
| Thickness of disc mm (in.)                   | 22 (0.876)     | 20 (0.787)    |
| Total runout of front axle assembly mm (in.) | -              | 0.06 (0.0024) |

If necessary, replace the brake disc.



Remove the drive shaft nut.

Jack up the vehicle and support it with jack stands.

Remove the wheel and tire.

Remove the front wheel brake assembly from the knuckle and suspend it with a wire.


### NOTE

**Brake hose does not need to be disconnected from brake calliper. Be careful not to depress brake pedal, or piston will popout.**

Disconnect the lower arm ball joint from the knuckle using the Special Tool (09568-31000).

Remove the wheel speed sensor mounting bolt and wire clamp and then remove the wheel speed sensor. (For ABS vehicle only).


Disconnect the tie rod and ball joint from the knuckle using the special tool.




## NOTE

1. Be sure to tie the cord of the special tool to the nearby part.
2. Loose the nut, but do not remove it.

Disconnect the drive shaft from the hub using the special tool.



Remove the hub and knuckle as an assembly from the strut.



Check the hub for cracks and the splines for wear.

Check the snap ring for cracking or damage.

Check the brake disc for scoring and damage.

Check the steering knuckle for cracks.

Check for a defective bearing. (Refer to "Wheel bearing trouble shooting".)

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSTALLATION

Install parts to torque specifications.

Be sure to install the washer and wheel bearing nut in the specified direction.

After installing the wheel, lower the vehicle to the ground and tighten the wheel bearing nut.


If the position of the split pin holes do not match, tighten the nut up to 260 Nm (2600 kg.cm, 188 lb.ft) maximum.

Install the split pin in the first matching holes and bend it over.

|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## COMPONENTS




Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## REMOVAL

Remove the fluid level warning device connector.

Disconnect the brake lines from the master cylinder, and plug the opening ports.




## CAUTION

**Do not allow brake fluid to remain on a painted surface. Wash it off immediately.**

Remove the master cylinder mounting nuts. Disconnect the proportioning valve mounting bracket, then lift out the master cylinder.

Remove the reservoir cap and drain the brake fluid into a suitable container.


Remove the reservoir from the master cylinder.



## NOTE

**If necessary, support the master cylinder in a vise at its flange not at its bore.**

While depressing the piston, remove the snap ring.



Remove the primary and secondary piston from the master cylinder, and then push the secondary piston through the master cylinder by using a screw driver and then remove the secondary piston stopper pin by slightly tilting the master cylinder.

## NOTE

1. Be careful not to damage the cylinder bore.
1. Do not disassemble the primary and secondary piston assemblies.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSPECTION

Check the master cylinder bore for rust or scoring.


Check the primary and secondary pistons for rust, scoring, wear, damage or deterioration.

Check the primary and secondary piston springs for deterioration.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## ASSEMBLY


Apply the specified brake fluid to the inner surface of the master cylinder body and to the outside of the secondary and primary pistons.



Recommended brake fluid: DOT 3 or equivalent

Installation is the reverse of the removal procedure.

Depress the primary piston and install the snap ring in the cylinder bore groove as illustrated.



Install the reservoir cap on the reservoir.

Lubricate the two grommets at both inside and outside with genuine brake fluid and then insert them into the master cylinder body.

### NOTE


**Whenever the reservoir is replaced, the grommets must also be replaced.**

Press the reservoir into the master cylinder body with the fluid level indicator socket facing inboard. The reservoir should snap in place indicating that it is secure as illustrated.

Connect the fluid level warning connector in the socket on the reservoir.




Install the master cylinder on the brake booster with two nuts.



| TORQUE SPECIFICATION |  |
|----------------------|--|
| Nut                  | 8-12 Nm ( 80-120 kg·cm,<br>6-9 lb·ft ) |

Connect two brake tubes and fluid level warning connector.



| TORQUE SPECIFICATION |   |
|----------------------|---|
| Brake tube flare nut | 13-17 Nm ( 130-170<br>kg·cm, 9-12 lb·ft ) |

Fill the master cylinder reservoir with brake fluid and bleed the system.

|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## PROPORTIONING VALVE

Do not disassemble the proportioning valve. The proportioning valve regulates the distribution of fluid pressure to the front and rear brakes to prevent skidding in the event of rear wheel lock and to obtain a higher brake efficiency.


### PROPORTIONING VALVE FUNCTION TEST

Connect two pressure gauges, one to the input side and one to the output side of the proportioning valve.

NOTE

Be sure to bleed the system after you connect the pressure gauges.

With the brakes applied, measure the input pressure and the output pressure. If the measured pressures are within the ranges as illustrated, the proportioning valve is good.



Reconnect the brake lines in their original positions and bleed the system.

NOTE


This figure shows characteristics of the proportioning valve during pressure increase.

|   |          |
|---|----------|
| A | 51 ± 3.5 |
| B | 80       |
| C | 40       |
| D | 140      |
| E | 67 ± 4   |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## PROPORTIONING VALVE INSTALLATION

Install the brake lines according to the illustration.



Tighten the flare nuts and bleed the system.

| TORQUE SPECIFICATION             |   |
|----------------------------------|---|
| Brake tube flare nut             | 13-17 Nm ( 130-170 kg·cm, 9-12 lb·ft )  |
| Proportioning valve mounting nut | 8-12 Nm ( 80-120 kg·cm, 5.8-8.7 lb·ft ) |


|   |                          |
|---|--------------------------|
| <b>SERVICE MANUAL</b>                                       |                          |
| Applies to: <a href="#">Hyundai Coupe/Tiburon 1998-2001</a> |                          |
| <b>GROUP</b>  |                          |
| Brake Systems   | Conventional BrakeSystem |

Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)


## DISASSEMBLY

Remove the wheel.


Remove the brake fluid hose.




Remove the caliper assembly mounting bolts (2EA).



Remove the brake pad and caliper assembly.




Remove the parking cable after disconnecting the parking cable mounting clip.



Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## COMPONENTS




**TORQUE : Nm (kg·cm, lb·ft)**

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSPECTION

Check the pads for wear or oil contamination and replace if necessary.



## NOTE

The pads for the right and left wheels should be replaced at the same time,

Pad thickness wear limit: 0.8 mm

Check the leading and trailing shoe keys and retaining screw for damage, or wear. Replace the keys and retaining screw at the same time the pads are replaced.


Check for worn or damaged dust boots if dust or mud has entered the caliper assembly through this seal, the caliper assembly must be replaced or rebuilt.

Before replacing the brake pads, remove brake fluid from the master cylinder reservoir until it is half full.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## ASSEMBLY

Check for worn, damaged, or rusted piston bore and piston.



Replace the damaged parts if necessary.


Check for damaged piston seal, boot, and pin insulators.

Apply a recommended lubricant to the following parts:

| Parts                | Recommended lubricant | Quantity    |
|----------------------|-----------------------|-------------|
| Piston seal          | Brake fluid (Dot 3)   | As required |
| Cylinder inner side  | Brake fluid (Dot 3)   | As required |
| Piston boot          | Brake fluid (Dot 3)   | As required |
| Piston outer surface | Brake fluid (Dot 3)   | As required |


|                      |               |             |
|----------------------|---------------|-------------|
| Guide-rod insulation | Rubber grease | As required |
|----------------------|---------------|-------------|

push the piston into the caliper with special tool.










Remove the shoe return lower spring, shoe hold down spring.

Remove the shoes and adjuster as an assembly.




Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)

## INSPECTION


Measure the brake drum inside diameter.

Check the runout of the brake drum using a dial indicator.




|                              | Standard value | Service limit  |
|------------------------------|----------------|----------------|
| Inside diameter              | 203.2 (8)      | 205.2 (8.079)  |
| Out-of-rounded of brake drum | -              | 0.015 (0.0006) |

Measure the brake shoe lining thickness.




|                           | Standard value | Service limit |
|---------------------------|----------------|---------------|
| Lining thickness mm (in.) | 4.05 (0.159)   | 1.5 (0.059)   |



- Inspect the brake lining and drum for proper contact.
  - Inspect the wheel cylinder outside for excessive corrosion and damage.
  - Inspect the backing plate for wear or damage.
- Return to Main Menu(s):    [Mechanical Manual](#)    [Electrical Manual](#)

## INSTALLATION

Apply the specified grease to the locations indicated in the illustration and to each component.




- Shoe and backing plate contact surfaces


Shoe and anchor plate contact surfaces

Recommended grease: Multipurpose grease SAE J310, NLGI No.2

Install the shoe hold down pin.




Assemble the return spring with the push rod shortened.



After assembling the drum components, pull the parking brake lever all the way up several times.

Return to Main Menu(s): [Mechanical Manual](#) [Electrical Manual](#)


## WHEEL CYLINDER REPLACEMENT



Remove the brake shoe.

Disconnect the brake tube.

Remove the wheel cylinder assembly.




Remove the dust boot.

Remove the piston and piston cup.

Drive out the return spring.

Before assembling the wheel cylinder, inspect the following points.



Check the cylinder and piston for wear, damage and rust.

Check the cylinder body for damage and cracks.

Check the contact surface of the piston and shoes for wear.

Check the piston spring for looseness.

Assembly is the reverse of the removal procedure.

### **NOTE**

1. Clean the cylinder and inner part with isopropyl alcohol before assembly.
2. Apply enough brake fluid to piston cups and cylinder.
3. Be sure to use new piston cups and dust boots.

### **NOTE**

Be careful not to lose the steel ball in the bleeder