

## GENESIS COUPE(BK) > 2013 > G 3.8 GDI > Engine Electrical System

### Engine Electrical System > General Information > Specifications

#### Specifications

#### Ignition System

Items		Specification
Ignition coil	Primary resistance	$0.62 \pm 10 \%$
	Secondary resistance	$7.0\text{k}\Omega \pm 15 \%$
Spark plugs	Type	SILZKR7B11
	Gap	1.0 ~ 1.1 mm (0.0394 ~ 0.0433 in.)

#### Starting System

Items			Specification
Starter	Rated voltage		12 V, 1.7 kW
	No. of pinion teeth		13
	No-load characteristics	Voltage	11.5 V
		Ampere	85A, MAX
		Speed	2,550 rpm, MIN

#### Charging System

Items		Specification
Alternator	Rate voltage	13.5 V, 130A
	Speed in use	1,500 ~ 18,000 rpm
	Voltage regulator	IC regulator built-in type
	Regulator setting voltage	14.2 ~ 14.8V
Battery	Type	64 - 28 FL
	Cold cranking amperage [at - 18°C(-0.4°F)]	660A
	Reserve capacity	145 min
	Specific gravity [at 25°C(77°F)]	$1.280 \pm 0.01$


**NOTE**

- COLD CRANKING AMPERAGE is the amperage a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2V or greater at a specified temperature.
- RESERVE CAPACITY RATING is amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5V at 26.7°C(80.1°F).

Battery type notation: MF 48 - 23 G L

① ② ③ ④ ⑤

- ① : Battery type
  - MF: Maintenance Free
- ② : Battery capacity (5HR)
  - 48: 48 AH
- ③ : Battery length (A)
  - 23: 230 mm (9.06 in.)
- ④ : Battery width (B)
  - A: 127 mm (5.00 in.)
  - B: 129 mm (5.08 in.)
  - C: 132 mm (5.20 in.)
  - D: 135 mm (5.31 in.)
  - E: 154 mm (6.06 in.)
  - F: 173 mm (6.81 in.)
  - G: 75 mm (6.89 in.)
  - H: 176 mm (6.93 in.) or above
- ⑤ : Terminal location (C)
  - L: Positive terminal is left
  - R: Positive terminal is right



## Engine Electrical System > General Information > Troubleshooting

### Troubleshooting

### Ignition System

Symptom	Suspect area	Remedy
Engine will not start or is hard to start (Crank OK)	Ignition lock switch	Inspect ignition lock switch, or replace as required
	Ignition coil	Inspect ignition coil, or replace as required
	Spark plugs	Inspect spark plugs, or replace as required
	Ignition wiring disconnected or broken	Repair wiring, or replace as required
Rough idle or stalls	Ignition wiring	Repair wiring, or replace as required
	Ignition coil	Inspect ignition coil, or replace as required
Engine hesitates/poor acceleration	Spark plugs and spark plug cables	Inspect spark plugs / cable, or replace as required
	Ignition wiring	Repair wiring, or replace as required
Poor mileage	Spark plugs and spark plug cables	Inspect spark plugs / cable, or replace as required

### Charging System

Symptom	Suspect area	Remedy
Charging warning indicator does not light with ignition switch "ON" and engine off.	Fuse blown	Check fuses
	Light burned out	Replace light
	Wiring connection loose	Tighten loose connection
	Electronic voltage regulator	Replace alternator
	Communication error	Inspect wiring between ECM-Regulator Inspect ECM output signal /or replace alternator as required
Charging warning indicator does not go out with engine running. (Battery requires frequent recharging)	Drive belt loose or worn	Adjust belt tension or replace belt
	Battery cable loose, corroded or worn	Inspect cable connection, repair or replace cable
	Electronic voltage regulator or alternator	Replace alternator
	Wiring	Repair or replace wiring
	Battery condition detection error	Replace battery sensor
Overcharge	Electronic voltage regulator	Replace alternator
	Voltage sensing wire	Repair or replace wiring
Discharge	Drive belt loose or worn	Adjust belt tension or replace belt
	Wiring connection loose or short circuit	Inspect wiring connection, repair or replace wiring

	Electronic voltage regulator or alternator	Replace alternator
	Poor grounding	Inspect ground or repair
	Worn battery	Replace battery
	Bad electrical load	Replace electrical load

### Starting System

Symptom	Suspect area	Remedy
Engine will not crank	Battery charge low	Charge or replace battery
	Battery cables loose, corroded or worn out	Repair or replace cables
	Transmission range switch (Vehicle with automatic transmission only)	Refer to AT group-automatic transmission
	Fuse blown	Replace fuse
	Starter motor faulty	Replace
	Ignition switch faulty	Replace
Engine cranks slowly	Battery charge low	Charge or replace battery
	Battery cables loose, corroded or worn out	Repair or replace cables
	Starter motor faulty	Replace
Starter keeps running	Starter motor	Replace
	Ignition switch	Replace
Starter spins but engine will not crank	Short in wiring	Repair wiring
	Pinion gear teeth broken or starter motor	Replace
	Ring gear teeth broken	Replace drive plate or torque converter

### Engine Electrical System > General Information > General Information

The Micro 570 Analyzer (Canada only)

The Micro 570 Analyzer provides the ability to test the charging and starting systems, including the battery, starter and alternator.

#### CAUTION

Because of the possibility of personal injury, always use extreme caution and appropriate eye protection when working with batteries.


When charging battery by test result, Battery must be fully charged.

To get accurate test result, battery surface voltage must have subsided ahead before test when you test battery after charged. (See following Battery Test Results)




### Keypad

The Micro 570 button on the key pad provide the following functions :



### Battery Test Procedure


1. Connect the tester to the battery.
  - A. Red clamp to battery positive (+) terminal.
  - B. Black clamp to battery negative (-) terminal.




#### CAUTION

Connect clamps securely. If "CHECK CONNECTION" message is displayed on the screen, reconnect clamps securely.

2. The tester will ask if the battery is connected "IN-VEHICLE" or "OUT-OF-VEHICLE". Make your selection by pressing the arrow buttons; then press ENTER.




3. Select CCA and press the ENTER button.

**NOTE**


CCA : Cold cranking amps, is an SAE specification for cranking battery at  $-0.4^{\circ}\text{F}$  ( $-18^{\circ}\text{C}$ ).

4. Set the CCA value displayed on the screen to the CCA value marked on the battery label by pressing up and down buttons and press ENTER.

**NOTE**


The battery ratings(CCA) displayed on the tester must be identical to the ratings marked on battery label.

5. The tester will conduct battery test.



6. The tester displays battery test results including voltage and battery ratings.

Refer to the following table and take the appropriate action as recommended by the Micro 570.



### Battery Test Results

Result On Printer	Remedy
GOOD BATTERY	No action is required.
GOOD RECHARGE	Battery is in a good state. Recharge the battery and use. You have to follow instruction below when you charge battery and retest, otherwise test result can be inaccurate. (See 'Charge and Retest method after battery charge' below.)
CHARGE & RETEST	Battery is not charged properly. - Charge and test the battery again. You have to follow instruction below when you charge battery and retest, otherwise test result can be inaccurate. (See 'Charge and Retest method after battery charge' below.)
REPLACE BATTERY	Replace battery and recheck the charging system. - Improper connection between battery and vehicle cables may cause "REPLACE BATTERY". Retest the battery after removing cables and connecting the tester to the battery terminal directly prior to replacing the battery.
BAD CELL-REPLACE	Charge and retest the battery. - If the Micro 570 recommends "REPLACE BATTERY", replace the battery and recheck the charging system.

[Charge and Retest method after battery charge]

### Battery charge

Set battery charger to 'Auto Mode' (The Mode that charging current drops as the battery charges.) and charge battery until charging current down close to zero or the charger alerts you with an alarm when charge is complete. (Minimum charging time recommended: More than 3 hours with Auto Mode that explained above)

A. If battery is not fully charged, battery surface voltage will be high while the amount of current charged (CCA) in battery is low. If you measure the battery under this condition, tester may misjudge that battery sulfation occurred because the amount of current in battery is too low in comparison with battery voltage.

\* Surface voltage: When battery is charged electrolyte temperature increases and chemical reaction become active resulting in an excessive increase of battery voltage.

It is known that it takes approximate one day to subside this increased surface voltage completely.

### Battery Test after charge

Do not test battery right after the charge. Test battery after battery surface voltage has subsided as instructed in the following procedure.


- (1) When battery charge is complete, install the battery in the vehicle.
- (2) Put IG key to ON position and turn on head lamp with low beam, and wait 5 minutes. (Discharge for 5 minutes)
- (3) Turn off the head lamp and IG key, and wait 5 minutes. (Waiting for 5 minutes)
- (4) Remove +, - cable from the battery and test battery.

### WARNING


Whenever filing a claim for battery, the print out of the battery test results must be attached.

### Starter Test Procedure

7. After the battery test, press ENTER immediately for the starter test.




8. Start the engine.





9. Cranking voltage and starter test results will be displayed on the screen.

Refer to the following table and take the appropriate action as recommended by the Micro 570.



### Starter Test Results


Result On Printer	Remedy
CRANKING VOLTAGE NORMAL	System shows a normal starter draw.
CRANKING VOLTAGE LOW	Cranking voltage is lower than normal level. - Check starter.
CHARGE BATTERY	The state of battery charge is too low to test. - Charge the battery and retest.
REPLACE BATTERY	Replace battery. - If the vehicle is not started though the battery condition of "GOOD BATTERY" is displayed, check wiring for open circuit, battery cable connection, starter and repair or replace as necessary. - If the engine does crank, check fuel system.

#### NOTE


When testing the vehicle with old diesel engines, the test result will not be favorable if the glow plug is not heated. Conduct the test after warming up the engine for 5 minutes.

### Charging System Test Procedure




10. Press ENTER to begin charging system test.




11. The tester displays the actual voltage of alternator.  
Press ENTER to continue.




12. Turn off all electrical load and rev engine for 5 seconds with pressing the accelerator pedal. (Follow the instructions on the screen)





13. The message that engine RPM is detected will be displayed on the screen. Press ENTER to continue.




14. If the engine RPM is not detected, press ENTER after revving engine.




15. The tester will conduct charging system test during loads off.





16. Turn on electrical loads (air conditioner, lamps, audio and etc). Press ENTER to continue.




17. The tester will conduct charging system test during loads on.




18. Rev engine for 5 seconds with pressing the accelerator pedal. (Follow the instructions on the screen)







19. The message that engine RPM is detected will be displayed on the screen. Press ENTER to continue.



20. If the engine RPM is not detected, press ENTER after revving engine.






21. Turn off electrical loads (air conditioner, lamps, audio and etc). Turn the engine off.



22. Charging voltage and charging system test results will be displayed on the screen.

Shut off engine and disconnect the tester clamps from the battery. Refer to the following table and take the appropriate action as recommended by the Micro 570.



### Charging System Test Results

Result On Printer	Remedy
CHARGING SYSTEM NORMAL / DIODE RIPPLE NORMAL	Charging system is normal.
NO CHARGING VOLTAGE	Alternator does not supply charging current to battery. - Check belts, connection between alternator and battery and replace belts or cable or alternator as necessary.
LOW CHARGING VOLTAGE	Alternator does not supply charging current to battery and electrical load to system fully. - Check belts and alternator and replace as necessary.
HIGH CHARGING VOLTAGE	The voltage from alternator to battery is higher than normal limit during voltage regulating. - Check connection and ground and replace regulator as necessary. - Check electrolyte level in the battery.
EXCESS RIPPLE DETECTED	One or more diodes in the alternator is not functioning properly. - Check alternator mounting and belts and replace as necessary.

**Engine Electrical System > Ignition System > Description and Operation****Description**

Ignition timing is controlled by the electronic control ignition timing system. The standard reference ignition timing data for the engine operating conditions are preprogrammed in the memory of the ECM (Engine Control Module). The engine operating conditions (speed, load, warm-up condition, etc.) are detected by the various sensors. Based on these sensor signals and the ignition timing data, signals to interrupt the primary current are sent to the ECM. The ignition coil is activated, and timing is controlled.



**Engine Electrical System > Ignition System > Repair procedures****On-vehicle Inspection****Spark Test**

1. Disconnect the battery negative cable.

**Tightening torque :**


7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

2. Remove the surge tank. (RH only)  
(Refer to Engine Mechanical System - "Intake And Exhaust System")
3. Remove the LH/RH ignition coil connectors (A) and then, remove the ignition coil.




**NOTE**

When removing the ignition coil connector, pull the lock pin(A) and push the clip(B).



4. Using a spark plug socket, remove the spark plug.
5. Install the spark plug to the ignition coil.
6. Ground the spark plug to the engine.



7. Check if spark occurs while engine is being cranked.

**NOTE**

To prevent fuel being injected from injectors while the engine is being cranked, disconnect the fuel pump connector.

Crank the engine for no more than 5 ~ 10 seconds.

8. Inspect all the spark plugs.
9. Using a spark plug socket, install the spark plugs.

**Tightening torque :**

14.7 ~ 24.5N.m (1.5 ~ 2.5kgf.m, 10.8 ~ 18.1lb-ft)


10. Install the ignition coils.

**Tightening torque :**

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)





## 11. Reconnect the ignition coil connector.




Inspect Spark Plug

1. Remove the LH/RH ignition coil connectors (A) and then, remove the ignition coil.

**NOTE**

When removing the ignition coil connector, pull the lock pin(A) and push the clip(B).




2. Using a spark plug socket, remove the spark plug.

**CAUTION**

Be careful that no contaminants enter through the spark plug holes.

3. Inspect the electrodes (A) and ceramic insulator (B).




### Inspection Of Electrodes

Condition	Dark deposits	White deposits
Description	<ul style="list-style-type: none"> <li>- Fuel mixture too rich</li> <li>- Low air intake</li> </ul>	<ul style="list-style-type: none"> <li>- Fuel mixture too lean</li> <li>- Advanced ignition timing</li> <li>- Insufficient plug tightening torque</li> </ul>

4. Check the electrode gap (A).


### Standard :

1.0 ~ 1.1 mm (0.0394 ~ 0.0433 in.)



Inspect Ignition Coil

1. Measure the primary coil resistance between terminals (+) and (-).



---

**Standard value:**  $0.62\Omega \pm 10\%$

---

## Removal and Installation

### Ignition Coil



1. Remove the LH/RH ignition coil connectors (A) and then, remove the ignition coil.

---

#### **Tightening torque :**


9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

---



**NOTE**

When removing the ignition coil connector, pull the lock pin(A) and push the clip(B).



2. Installation is the reverse of removal.

### Engine Electrical System > Charging System > Description and Operation

#### Description


The charging system includes a battery, an alternator with a built-in regulator, and the charging indicator light and wire.

The Alternator has built-in diodes, each rectifying AC current to DC current.

Therefore, DC current appears at alternator "B" terminal.

The regulator regulates the charging voltage to maintain ECM signal.

The main components of the alternator are the rotor, stator, rectifier, capacitor brushes, bearings, regulator and V-ribbed belt pulley.



1. Brush
2. Drive belt pulley
3. Stator
4. Rotor

### Engine Electrical System > Charging System > Repair procedures

#### On-vehicle Inspection

**CAUTION**

- Check that the battery cables are connected to the correct terminals.
- Disconnect the battery cables when the battery is given a quick charge.
- Never disconnect the battery while the engine is running.


**Inspect Drive Belt**

Visually check the belt for excessive wear, frayed cords etc.

If any defect has been found, replace the drive belt.

**NOTE**

Cracks on the rib side of a belt are considered acceptable. If the belt has chunks missing from the ribs, it should be replaced.

**Visually Check Alternator Wiring And Listen For Abnormal Noises**

1. Check that the wiring is in good condition.
2. Check that there is no abnormal noise from the alternator while the engine is running.

**Check Discharge Warning Light Circuit**

1. Warm up the engine and then turn it off.
2. Turn off all accessories.
3. Turn the ignition switch "ON". Check that the discharge warning light is lit.
4. Start the engine and Check that the light goes off.

If the light does not go off as specified, troubleshoot the discharge light circuit, drive belt, battery cable, and signal between ECM-Regulator.


**Voltage Drop Test Of Alternator Output Wire**

This test determines whether or not the wiring between the alternator "B" terminal and the battery (+) terminal is good by the voltage drop method.

**Preparation**

1. Turn the ignition switch to "OFF".

2. Disconnect the output wire from the alternator "B" terminal. Connect the (+) lead wire of ammeter to the "B" terminal of alternator and the (-) lead wire of ammeter to the output wire. Connect the (+) lead wire of voltmeter to the "B" terminal of alternator and the (-) lead wire of voltmeter to the (+) terminal of battery.



### Test

1. Start the engine.
2. Turn on the headlamps and blower motor, and set the engine speed until the ammeter indicates 20A. And then, read the voltmeter at this time.

### Result

1. The voltmeter may indicate the standard value.

---

**Standard value:** 0.2V max

---

2. If the value of the voltmeter is higher than expected (above 0.2V max.), poor wiring is suspected. In this case check the wiring from the alternator "B" terminal to the battery (+) terminal. Check for loose connections, color change due to an over-heated harness, etc. Correct them before testing again.
3. Upon completion of the test, set the engine speed at idle. Turn off the headlamps, blower motor and the ignition switch.

### Output Current Test

This test determines whether or not the alternator gives an output current that is equivalent to the normal output.


### Preparation

1. Prior to the test, check the following items and correct as necessary.  
Check the battery installed in the vehicle to ensure that it is in good condition. The battery checking method is described in the section "Battery".  
The battery that is used to test the output current should be one that has been partially discharged. With a fully charged battery, the test may not be conducted correctly.  
Check the tension of the alternator drive belt. The belt tension check method is described in the section "Inspect drive belt".
2. Turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Disconnect the alternator output wire from the alternator "B" terminal.
5. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Be sure to connect the (-) lead wire of the ammeter to the disconnected output wire.

### NOTE

Tighten each connection securely, as a heavy current will flow. Do not rely on clips.

6. Connect a voltmeter (0 to 20V) between the "B" terminal and ground. Connect the (+) lead wire to the alternator "B" terminal and (-) lead wire to a good ground.
7. Attach an engine tachometer and connect the battery ground cable.
8. Leave the engine hood open.



### Test

1. Check to see that the voltmeter reads as the same value as the battery voltage. If the voltmeter reads 0V, and the open circuit in the wire between alternator "B" terminal and battery (+) terminal or poor grounding is suspected.
2. Start the engine and turn on the headlamps.
3. Set the headlamps to high beam and the heater blower switch to HIGH, quickly increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.

#### NOTE

After the engine start up, the charging current quickly drops.  
Therefore, the above operation must be done quickly to read the maximum current value correctly.

### Result

1. The ammeter reading must be higher than the limit value. If it is lower but the alternator output wire is in good condition, remove the alternator from the vehicle and test it.

---

**Limit value :** 60% of the voltage rate

---

#### NOTE

- The output current value changes with the electrical load and the temperature of the alternator itself. Due to temperature the maximum output current may not be obtained. If such is the case, keep the headlamps on to increase the electrical load.  
The nominal output current may not be obtained if the temperature of the alternator itself or ambient temperature is too high.  
In such a case, reduce the temperature before testing again.

2. Upon completion of the output current test, lower the engine speed to idle and turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Remove the ammeter and voltmeter and the engine tachometer.
5. Connect the alternator output wire to the alternator "B" terminal.
6. Connect the battery ground cable.


### Regulated Voltage Test

The purpose of this test is to check that the electronic voltage regulator controls voltage correctly.

### Preparation



1. Prior to the test, check the following items and correct if necessary.  
Check that the battery installed on the vehicle is fully charged. The battery checking method is described in the section "Battery".  
Check the alternator drive belt tension. The belt tension check method is described in the section "Inspect drive belt".
2. Turn ignition switch to "OFF".
3. Disconnect the battery ground cable.
4. Connect a digital voltmeter between the "B" terminal of the alternator and ground. Connect the (+) lead of the voltmeter to the "B" terminal of the alternator. Connect the (-) lead to good ground or the battery (-) terminal.
5. Disconnect the alternator output wire from the alternator "B" terminal.
6. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire.  
Connect the (-) lead wire of the ammeter to the disconnected output wire.
7. Attach the engine tachometer and connect the battery ground cable.



#### Test

1. Turn on the ignition switch and check to see that the voltmeter indicates the following value.

---

**Voltage:** Battery voltage

---

If it reads 0V, there is an open circuit in the wire between the alternator "B" terminal and the battery (-) terminal/ or bad ground.

2. Start the engine. Keep all lights and accessories off.
3. Run the engine at a speed of about 2,500 rpm and read the voltmeter when the alternator output current drops to 10A or less

#### Result

1. If the voltmeter reading doesn't agree with the standard value, the voltage regulator or the alternator is faulty.

---

**Regulating voltage :** 14.2 ~ 14.8V

---

2. Upon completion of the test, reduce the engine speed to idle, and turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Remove the voltmeter and ammeter and the engine tachometer.
5. Connect the alternator output wire to the alternator "B" terminal.
6. Connect the battery ground cable.

### Engine Electrical System > Charging System > Alternator > Repair procedures

#### Removal and Installation

1. Disconnect the battery negative cable


---

**Tightening torque:**


7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

---


2. Remove the air cleaner assembly. (Refer to Engine Mechanical System - "Intake And Exhaust System")
3. Turn the tensioner counterclockwise and loosen, then remove the drive belt (A).



4. Disconnect the alternator connector (A) and cable (B) from the 'B' terminal.




5. Remove the reservoir tank (A).



6. Remove the alternator (A).

**Tightening torque :**

26.5 ~ 33.3 N.m (2.7 ~ 3.4 kgf.m, 19.5 ~ 24.6 lb-ft)




7. Installation is reverse order of removal.

**Engine Electrical System > Charging System > Battery > Description and Operation**

**Description**

1. The maintenance-free battery is, as the name implies, totally maintenance free and has no removable battery cell caps.
2. Water never needs to be added to the maintenance-free battery.
3. The battery is completely sealed, except for small vent holes in the cover.




**NOTE**

After disconnecting then reconnecting the battery negative cable, reset some parts that require the reset procedures. (Refer to BE group - General information)

**Engine Electrical System > Charging System > Battery > Components and Components Location**

**Components**



Torque : N.m (kgf.m, lb-ft)

- |                           |                             |
|---------------------------|-----------------------------|
| 1. Battery insulation pad | 3. Battery tray             |
| 2. Battery                | 4. Battery mounting bracket |

## Engine Electrical System > Charging System > Battery > Repair procedures

### Removal and Installation

1. Remove the battery.
    - (1) Disconnect the battery negative terminal (A).
    - (2) Disconnect the battery positive terminal (B).
- 

**Tightening torque**

(-) terminal :

7.8 ~ 9.8 N.m (0.8 ~ 1.0 kgf.m, 5.8 ~ 7.2 lb-ft)

(+) terminal :

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)

---


- (3) Remove the battery mounting bracket (C).
- 

**Tightening torque :**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)

---

- (4) Remove the battery (D).




2. Remove the battery tray (A).
- 

**Tightening torque :**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)

---




3. Installation is the reverse order of removal.

**CAUTION**

When installing the battery, fix the mounting bracket on the tray correctly.

## Inspection

## Battery Diagnostic Flow



## Vehicle parasitic current inspection

1. Turn the all electric devices OFF, and then turn the ignition switch OFF.
2. Close all doors except the engine hood, and then lock all doors.
  - (1) Disconnect the hood switch connector.
  - (2) Close the trunk lid.
  - (3) Close the doors or remove the door switches.

3. Wait a few minutes until the vehicle's electrical systems go to sleep mode.

**NOTE**

For an accurate measurement of a vehicle parasitic current, all electrical systems should go to sleep mode. (It takes at least one hour or at most one day.) However, an approximate vehicle parasitic current can be measured after 10~20 minutes.


4. Connect an ammeter in series between the battery (-) terminal and the ground cable, and then disconnect the clamp from the battery (-) terminal slowly.

**CAUTION**

Be careful that the lead wires of an ammeter do not come off from the battery (-) terminal and the ground cable to prevent the battery from being reset. In case the battery is reset, connect the battery cable again, and then start the engine or turn the ignition switch ON for more than 10 sec. Repeat the procedure from No. 1.

To prevent the battery from being reset during the inspection,

- 1) Connect a jump cable between the battery (-) terminal and the ground cable.
- 2) Disconnect the ground cable from the battery (-) terminal.
- 3) Connect an ammeter between the battery (-) terminal and the ground cable.
- 4) After disconnecting the jump cable, read the current value of the ammeter.



5. Read the current value of the ammeter.
- A. If the parasitic current is over the limit value, search for abnormal circuit by removing a fuse one by one and checking the parasitic current.
  - B. Check the parasitic current again, and search for suspected unit by removing a unit connected with the abnormal circuit one by one.

---

**Limit value (after 10~20 min.) : Below 50mA**

---

## Cleaning


1. Make sure the ignition switch and all accessories are in the OFF position.

## 2. Remove the battery from the vehicle.(Refer to Battery Removal in this group)

### CAUTION

Care should be taken in the event the battery case is cracked or leaking, to protect your skin from the electrolyte.

Heavy rubber gloves (not the household type) should be worn when removing the battery.



3. Inspect the battery tray for damage caused by the loss of electrolyte. If acid damage is present, it will be necessary to clean the area with a solution of clean warm water and baking soda. Scrub the area with a stiff brush and wipe off with a cloth moistened with baking soda and water.
4. Clean the top of the battery with the same solution as described above.
5. Inspect the battery case and cover for cracks. If cracks are present, the battery must be replaced.
6. Clean the battery posts with a suitable battery post tool.
7. Clean the inside surface of the terminal clamps with a suitable battery cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
8. Install the battery in the vehicle.
9. Connect the cable terminals to the battery post, making sure tops of the terminals are flush with the tops of the posts.
10. Tighten the terminal nuts securely.
11. Coat all connections with light mineral grease after tightening.

### CAUTION

When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries being charged or which have recently been charged. Do not break live circuit at the terminals of batteries being charged.

A spark will occur when the circuit is broken. Keep open flames away from battery.

## Engine Electrical System > Starting System > Description and Operation


### Description

The starting system includes the battery, starter, solenoid switch, ignition switch, inhibitor switch (A/T), ignition lock switch, connection wires and the battery cable.

When the ignition key is turned to the start position, current flows and energizes the starter motor's solenoid coil. The solenoid plunger and clutch shift lever are activated, and the clutch pinion engages the ring gear.

The contacts close and the starter motor cranks. In order to prevent damage caused by excessive rotation of the starter armature when the engine starts, the clutch pinion gear overruns.





1. Solenoid
2. Brush
3. Armature
4. Overrun clutch

## Engine Electrical System > Starting System > Repair procedures

### Troubleshooting Starter Circuit

#### NOTE


The battery must be in good condition and fully charged.

1. Disconnect the fuel pump connector
2. With the shift lever in N or P (A/T) or clutch pedal pressed (M/T), turn the ignition switch to "START"  
If the starter normally cranks the engine, starting system is OK. If the starter will not crank the engine at all, go to next step.  
If it won't disengage from the ring gear when you release key, check for the following until you find the cause.
  - A. Solenoid plunger and switch malfunction.
  - B. Dirty pinion gear or damaged overrunning clutch.
3. Check the battery condition. Check electrical connections at the battery, battery negative cable connected to the body, engine ground cables, and the starter for looseness and corrosion. Then try starting the engine again.  
If the starter cranks normally the engine, repairing the loose connection repaired the problem. The starting system is now OK.  
If the starter still does not crank the engine, go to next step.
4. Disconnect the connector from the S-terminal of solenoid. Connect a jumper wire from the B-terminal of solenoid to the S-terminal of solenoid.  
If the starter cranks the engine, go to next step.  
If the starter still does not crank the engine, remove the starter, and repair or replace as necessary.
5. Check the following items in the order listed until you find the open circuit.
  - A. Check the wire and connectors between the driver's under-dash fuse/relay box and the ignition switch, and between the driver's under-dash fuse/relay box and the starter.
  - B. Check the ignition switch (Refer to ignition system in BE Group).
  - C. Check the transaxle range switch connector or ignition lock switch connector.
  - D. Inspect the starter relay.


### Starter Solenoid Test

1. Disconnect the field coil wire from the M-terminal of solenoid switch.


2. Connect the battery as shown. If the starter pinion pops out, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.



3. Disconnect the battery from the M terminal. If the pinion does not retract, the hold-in coil is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




4. Disconnect the battery also from the body. If the pinion retracts immediately, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.



#### Free Running Test

1. Place the starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows.
2. Connect a test ammeter (100-ampere scale) and carbon pile rheostats as shown in the illustration.

3. Connect a voltmeter (15-volt scale) across starter motor.



4. Rotate carbon pile to the off position.

5. Connect the battery cable from battery's negative post to the starter motor body.

6. Adjust until battery voltage shown on the voltmeter reads 11.5volts.

7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

---


**Current : 85A MAX**

**Speed : 2,550 rpm MIN**

---

**Engine Electrical System > Starting System > Starter > Components and Components Location**

Components



1 . Front bracket	8 . Shield
2 . Planet gear shaft assembly	9 . Armature assembly
3 . Lever	10 . York assembly
4 . Lever packing	11 . Brush holder assembly
5 . Magnet switch	12 . Rear bracket
6 . Packing	13 . Through bolt
7 . Planet gear	

### Engine Electrical System > Starting System > Starter > Repair procedures

#### Removal and Installation

1. Disconnect the battery negative cable.

#### Tightening torque :


7.8 ~ 9.8 N.m (0.8 ~ 1.0 kgf.m, 5.8 ~ 7.2 lb-ft)

2. Remove the air cleaner assembly.  
(Refer to Engine Mechanical System - “Engine And Transmission Assembly”)
  3. Remove the under cover.  
(Refer to Engine Mechanical System - “Engine And Transmission Assembly”)
  4. Remove the starter cover (A).
- 


**Tightening torque :**

8.8 ~ 13.7 N.m (0.9 ~ 1.4 kgf.m, 6.5 ~ 10.1 lb-ft)

---



5. Disconnect the starter connector (A) and cable (B) from the 'B' terminal.



6. Set a jack to the oil pan.

**CAUTION**

Insert a lubber block between jack and oil pan to prevent the oil pan damage.


7. Loosen the engine mounting nut (A).

---

**Tightening torque :**

63.7 ~ 83.4 N.m (6.5 ~ 8.5 kgf.m, 47.0 ~ 61.5 lb-ft)

---

**NOTE**

Lift up the engine assembly slightly by using a jack to get access to the side of engine.

8. Remove the RH engine support bracket (A).

9. Remove the starter (B).

---

**Tightening torque :**

Support bracket bolt :

63.7 ~ 83.4 N.m (6.5 ~ 8.5 kgf.m, 47.0 ~ 61.5 lb-ft)


Starter bolt :

49.0 ~ 63.7 N.m (5.0 ~ 6.5 kgf.m, 36.2 ~ 47.0 lb-ft)

Starter nut :


42.1 ~ 53.9 N.m (4.3 ~ 5.5 kgf.m, 31.2 ~ 39.8 lb-ft)

---




Disassembly


1. Disconnect the M-terminal on the magnet switch assembly.




2. After loosening the 3 screws (A), detach the magnet switch assembly (B).




3. Loosen the through bolts (A).




4. Remove the brush holder assembly (A), yoke (B) and armature (C).




5. Remove the shield (A) and packing (B).




6. Remove the lever plate (A) and lever packing (B).



7. Disconnect the planet gear (A).




8. Disconnect the planet shaft assembly (A) and lever (B).







9. Press the stopper (A) using a socket (B).



10. After removing the stop ring (A) using stop ring pliers (B).




11. Disconnect the stopper (A), overrunning clutch (B), internal gear (C) and planet shaft (D).



12. Reassembly is the reverse of disassembly.

#### NOTE


Using a suitable pulling tool (A), pull the overrunning clutch stopper (C) over the stop ring (B).




## Inspection

**Armature Inspection And Test**

1. Remove the starter.
2. Disassemble the starter as shown at the beginning of this procedure.
3. Inspect the armature for wear or damage from contact with the permanent magnet. If there is wear or damage, replace the armature.



4. Check the commutator (A) surface. If the surface is dirty or burnt, resurface with emery cloth or a lathe within the following specifications, or recondition with #500 or #600 sandpaper (B).




5. Measure the commutator (A) runout.
  - A. If the commutator runout is within the service limit, check the commutator for carbon dust or brass chips between the segments.
  - B. If the commutator run out is not within the service limit, replace the armature.

**Commutator runout**

Standard (New): 0.05mm (0.0019in.) max

Service limit: 0.08mm (0.0031in.)




6. Check the mica depth (A). If the mica is too high (B), undercut the mica with a hacksaw blade to the proper depth. Cut away all the mica (C) between the commutator segments. The undercut should not be too shallow, too narrow, or v-shaped (D).


### Commutator mica depth

Standard (New) : 0.7 mm (0.0275in.)


Limit : 0.2mm (0.0079 in.)



7. Check for continuity between the segments of the commutator. If an open circuit exists between any segments, replace the armature.




8. Check with an ohmmeter that no continuity exists between the commutator (A) and armature coil core (B), and between the commutator and armature shaft (C). If continuity exists, replace the armature.




### Inspect Starter Brush

Brushes that are worn out, or oil-soaked, should be replaced.




### Starter Brush Holder Test

1. Make sure there is no continuity between the (+) brush holder (A) and (-) plate (B). If there is continuity, replace the brush holder assembly.



### Overrunning Clutch

1. Slide the overrunning clutch along the shaft.  
Replace it if it does not slide smoothly.
2. Rotate the overrunning clutch both ways.  
Does it lock in one direction and rotate smoothly in reverse? If it does not lock in either direction or it locks in both directions, replace it.



3. If the starter drive gear is worn or damaged, replace the overrunning clutch assembly. (the gear is not available separately).  
Check the condition of the flywheel or torque converter ring gear if the starter drive gear teeth are damaged.


### Cleaning

1. Do not immerse parts in cleaning solvent. Immersing the yoke assembly and/or armature will damage the insulation. Wipe these parts with a cloth only.
2. Do not immerse the drive unit in cleaning solvent. The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

## Engine Electrical System > Starting System > Starter Relay > Repair procedures

### Inspection


1. Remove the fuse box cover.
2. Remove the starter relay (A).



3. Using an ohmmeter, check that there is continuity between each terminal.

Terminal	Continuity
30 - 87	NO
85 - 86	YES


4. Apply 12V to terminal 85 and ground to terminal 86.  
Check for continuity between terminals 30 and 87.



5. If there is no continuity, replace the starter relay.
6. Install the starter relay.
7. Install the fuse box cover.

## Engine Electrical System > Cruise Control System > Schematic Diagrams

### System Block Diagram



### Component Parts And Function Outline

Component part		Function
Vehicle-speed sensor		Converts vehicle speed to pulse.
ECM		Receives signals from sensor and control switches.
Cruise control indicator		Illuminate when CRUISE main switch is ON (Built into cluster)
Cruise Control switches	ON/OFF switch	Switch for automatic speed control power supply.
	Resume/Accel switch	Controls automatic speed control functions by Resume/Accel switch (Set/Coast switch)
	Set/Coast switch	
Cancel switch	Cancel switch	Sends cancel signals to ECM.
	Brake-pedal switch	
	Transaxle range switch (A/T)	
ETS motor		Regulates the throttle valve to the set opening by ECM.

\* ETS : Electronic Throttle System

### Engine Electrical System > Cruise Control System > Description and Operation

#### Cruise Control

Cruise control system is engaged by the "ON/OFF" main switch located on right of steering wheel column. The system has the capability to cruise, coast, resume speed, and accelerate, and raise "tab-up" or lower "tab-down" set speed.

It also has a safety interrupt, engaged upon depressing brake or shifting select lever.

The ECM is the control module for this system.

The main components of cruise control system are mode control switches, transaxle range switch, brake switch, vehicle speed sensor, ECM and ETS motor that connect throttle body.

The ECM contains a low speed limit which will prevent system engagement below a minimum speed of 40km/h (25mph).

The operation of the controller is controlled by mode control switches located on steering wheel.

Transaxle range switch and brake switch are provided to disengage the cruise control system. When the brake pedal is depressed or select lever shifted, the cruise control system is electrically disengaged and the throttle is returned to the idle position.

#### **Cruise main switch**

Cruise control system is engaged by pressing the "ON/OFF" push button. Releasing the "ON/OFF" push button will release throttle, clears cruise memory speed, and puts vehicle in a non-cruise mode.

#### **Coast/Set switch**

COAST/SET switch located on right of steering wheel column has two positions - "Normal" and "Depressed". The set position - With COAST/SET switch depressed and then released the cruise speed will be set at the speed the vehicle was going when COAST/SET switch was released. The coast position - With COAST/SET switch fully depressed, driver can lower cruise speed. To decrease cruise speed, COAST/SET switch is held in, disengaging cruise control system. When vehicle has slowed to required cruise speed, releasing COAST/SET switch will re-engage system at new selected speed.

The tab down - To lower vehicle speed, cruise must be engaged and operating. Tab down is done by quickly pressing and releasing COAST/SET switch. Do not hold COAST/SET switch in depressed position.

Tab down is a function in which vehicle speed is decrease by 1 mph (1.6km/h)

#### **Resume/Accel switch**

RES/ACCEL switch located on right of steering wheel column has two positions - "Normal" and "Depressed".

The resume position - With RES/ACCEL switch depressed and then release, this switch also returns cruise control operation to last speed (Which is temporarily disengaged by Cancel switch or Brake pedal), setting when momentarily operating RES/ACCEL switch by constant acceleration.

The accel position - With RES/ACCEL switch depressed and held in, disengaging cruise control system, when vehicle has accelerated to required cruise speed, releasing RES/ACCEL switch will re-engage speed at new selected speed.

The tab up - To increase vehicle speed, the cruise must be engaged and operating.

Tab up is done by quickly pressing and releasing RES/ACCEL switch less than 0.5 second. Do not hold RES/ACCEL switch in depressed position. Tab up is a function in which cruise speed can be increased by 1mph (1.6km/h).

#### **Cancel switch**


Cruise control system is temporarily disengaged by pressing "CANCEL" switch.

Cruise speed canceled by this switch will be recovered by RES/ACCEL switch

### **Engine Electrical System > Cruise Control System > Troubleshooting**

#### **Trouble Symptom Charts**

#### **Trouble Symptom 1**



### Trouble Symptom 2

Trouble symptom	Probable cause	Remedy
The set vehicle speed varies greatly upward or downward "Surging" (repeated alternating acceleration and deceleration) occurs after setting	Malfunction of the vehicle speed sensor circuit	Repair the vehicle speed sensor system, or replace the part
	Malfunction of ECM	Check input and output signals at ECM

### Trouble Symptom 3

Trouble symptom	Probable cause	Remedy
The CC system is not canceled when the brake pedal is depressed	Damaged or disconnected wiring of the brake pedal switch	Repair the harness or replace the brake pedal switch
	Malfunction of the ECM signals	Check input and output signals at ECM



**Trouble Symptom 4**

Trouble symptom	Probable cause	Remedy
The CC system is not canceled when the shift lever is moved to the "N" position (It is canceled, however, when the brake pedal is depressed)	Damaged or disconnected wiring of inhibitor switch input circuit	Repair the harness or repair or replace the inhibitor switch
	Improper adjustment of inhibitor switch	
	Malfunction of the ECM signals	Check input and output signals at ECM

**Trouble Symptom 5**

Trouble symptom	Probable cause	Remedy
Cannot decelerate (coast) by using the SET switch	Temporary damaged or disconnected wiring of SET switch input circuit	Repair the harness or replace the SET switch
	Malfunction of the ECM signals	Check input and output signals at ECM

**Trouble Symptom 6**

Trouble symptom	Probable cause	Remedy
Cannot accelerate or resume speed by using the RESUME switch	Damaged or disconnected wiring, or short circuit, or RESUME switch input circuit	Repair the harness or replace the RESUME switch
	Malfunction of the ECM signals	Check input and output signals at ECM



**Trouble Symptom 7**

Trouble symptom	Probable cause	Remedy
CC system can be set while driving at a vehicle speed of less than 40km/h (25mph), or there is no automatic cancellation at that speed	Malfunction of the vehicle-speed sensor circuit	Repair the vehicle speed sensor system, or replace the part
	Malfunction of the ECM signals	Check input and output signals at ECM

**Trouble Symptom 8**


Trouble symptom	Probable cause	Remedy
The cruise main switch indicator lamp does not illuminate (But CC system is normal)	Damaged or disconnected bulb of cruise main switch indicator lamp	Repair the harness or replace the part.
	Harness damaged or disconnected	

**Engine Electrical System > Cruise Control System > Cruise Control Switch > Schematic Diagrams****Circuit Diagram**



CONNECTOR

NO	CONNECTOR
1	ILL(+)
2	ILL(-)
3	ACC(-)
4	ACC ON/OFF
5	ACC(-)
6	-
7	-
8	-




## Engine Electrical System > Cruise Control System > Cruise Control Switch > Repair procedures

### Inspection

### Measuring Resistance

1. Disconnect the cruise control switch connector from the control switch.




2. Measure resistance between terminals on the control switch when each function switch is ON (switch is depressed).

Function switch	Terminal	Resistance
Cruise Main	RH 3-4	$3.9\text{k}\Omega \pm 1\%$
Cancel	RH 3-5	$0\Omega \pm 1\%$
Set/Coast	RH 3-5	$220\Omega \pm 1\%$
Resume/Accel	RH 3-5	$910\Omega \pm 1\%$

3. If not within specification, replace switch.

#### Measuring Voltage

1. Connect the cruise control switch connector to the control switch.



2. Measure voltage between terminals on the harness side connector when each function switch is ON (switch is depressed).

Function switch	Terminal	Voltage
Cruise Main	RH 3-4	-
Cancel	RH 3-5	$0.0V \pm 0.22V$
Set/Coast	RH 3-5	$1.5V \pm 0.22V$
Resume/Accel	RH 3-5	$3.0V \pm 0.22V$

3. If not within specification, replace switch.